



Technology leads Intelligent life

Service Manual

ARV Outdoor Unit

ARV 6 All DC Inverter T1



ARV-H250/SR1MV

ARV-H280/SR1MV

ARV-H330/SR1MV



ARV-H400/SR1MV

ARV-H450/SR1MV

ARV-H500/SR1MV

ARV-H560/SR1MV

ARV-H610/SR1MV

2018.8

CONTENT

Part1 Refrigerant Circuit	4
1. Cooling Operation.....	5
2. Heating Operation	7
3. Component introduce	10
Part2 Installation.....	11
1. Preface of installation	12
2. Installation of Outdoor Unit.....	13
3. Pipes Laying	19
4. Welding	28
5. Gas Tightness Test.....	30
6. Vacuum Drying	36
7. Insulation	39
8. Additional refrigerant.....	42
9. Electrical Wiring.....	44
Part3 Commissioning	46
1. Preparatory work	47
2. Master unit setting	50
3. Commissioning	50
4. Parameter Setting (Main PCB)	58
5. Commissioning Based on Monitoring Software	65
6. IDU Parameter setting by Controller.....	99
35	99
Part4 Special Control	107
1. Special Control	108
Part5 Trouble shooting.....	117
1. IDU Error code table (No.16).....	118
2. ODU Error code table (No.65)	120
3. Indoor unit error code display	127

4. Outdoor unit error code display	129
5. Outdoor unit trouble shooting	133
6. Appendix.....	141
Part6 Control System	146
1. Controller Introduction	147
2. Remote controller	149
3. Wired Controller	154
4. Centralized Controller	158
5. Centralized Controller Software.....	177
6. BMS-MODBUS Protocol.....	189
7. BMS - BACNET Protocol.....	194
8. Wireless Network Centralized Control System	206


Part1 Refrigerant Circuit

1. Cooling Operation Chyba! Záložka není definována.
2. Heating Operation Chyba! Záložka není definována.
3. Component introduce Chyba! Záložka není definována.

1. Cooling Operation


ARV-H250/SR1MV, ARV-H280/SR1MV, ARV-H330/SR1MV

ARV-H400/SR1MV, ARV-H450/SR1MV



NO.	Component (Sensors)	Full name
1	T_{ho2}	Outlet temperature of PMV3
2	T_{def2}	Outlet temperature of sub-cooler
3	T_{ao}	Environment temperature
4	T_s	Gas-liquid separator outlet/Suction temperature
5	T_{ho1}	Condenser outlet temperature
6	T_{def1}	Defrost temperature
7	T_{d1}	Discharge of compressor 1#
8	T_{d3}	Oil temperature
9	T_{d4}	Liquid piping temperature of ODU


ARV-H500/SR1MV, ARV-H560/SR1MV, ARV-H610/SR1MV



NO.	Component (Sensors)	Full name
1	T _{ho2}	Outlet temperature of PMV3
2	T _{def2}	Outlet temperature of sub-cooler
3	T _{ao}	Environment temperature
4	T _s	Gas-liquid separator outlet/Suction temperature
5	T _{ho1}	Condenser outlet temperature
6	T _{def1}	Defrost temperature
7	T _{d1}	Discharge of compressor 1#
8	T _{d3}	Oil temperature
9	T _{d4}	Liquid piping temperature of ODU
10	T _{d2}	Discharge of compressor 2#


2. Heating Operation

ARV-H250/SR1MV, ARV-H280/SR1MV, ARV-H330/SR1MV, ARV-H400/SR1MV, ARV-H450/SR1MV



NO.	Component (Sensors)	Full name
1	T_{ho2}	Outlet temperature of PMV3
2	T_{def2}	Outlet temperature of sub-cooler
3	T_{ao}	Environment temperature
4	T_s	Gas-liquid separator outlet/Suction temperature
5	T_{ho1}	Condenser outlet temperature
6	T_{def1}	Defrost temperature
7	T_{d1}	Discharge of compressor 1#
8	T_{d3}	Oil temperature
9	T_{d4}	Liquid piping temperature of ODU

ARV-H500/SR1MV, ARV-H560/SR1MV, ARV-H610/SR1MV



NO.	Component (Sensors)	Full name
1	T_{ho2}	Outlet temperature of PMV3
2	T_{def2}	Outlet temperature of sub-cooler
3	T_{ao}	Environment temperature
4	T_s	Gas-liquid separator outlet/Suction temperature
5	T_{ho1}	Condenser outlet temperature
6	T_{def1}	Defrost temperature
7	T_{d1}	Discharge of compressor 1#
8	T_{d3}	Oil temperature
9	T_{d4}	Liquid piping temperature of ODU
10	T_{d2}	Discharge of compressor 2#


3. Component introduce

Component name	Main function
DC Inverter	DC inverter Compressor : Compressor work frequency range is 20~120 Hz.
HP Switch	High Pressure Switch: When refrigerant high pressure value over the target pressure value , switch valve is disconnected, signal is interrupted ,then stop running to protect the refrigerant system
OS	Oil Separator: To separate refrigeration oil and high pressure refrigerant
Filter	Filter impurities to avoid blockage of electronic expansion valve
SV1	Unload Valve
SV5/ SV6	Enhance vapor injection Valve
HP sensor	High Pressure Sensor: Detecting refrigerant system high pressure value
4-way valve	Change the refrigerant flow direction to achieve cooling or heating mode
Plate Heater	Sub-cooler: 5.5°C sub-cooling by plate heat exchanger make sure liquid refrigerant flow into evaporator Instead of gas-liquid refrigerant flow into evaporator , reduce Airflow noise and temperature fluctuation and support long piping length
SV3	Sub-cooling Valve
Refrigerant Cooling	Well cooled by refrigerant, ensuring the long life time of the PCB
PMV	EXV: throttling and reducing refrigerant pressure
LGS	Liquid-gas separator: To separate gas refrigerant and liquid refrigerant
LP Sensor	Low Pressure Sensor: Detecting refrigerant system low pressure value

Part2 Installation

1. Preface of installation Chyba! Záložka není definována.
2. Installation of Outdoor Unit Chyba! Záložka není definována.
3. Pipes Laying Chyba! Záložka není definována.
4. Welding Chyba! Záložka není definována.
5. Gas Tightness Test..... Chyba! Záložka není definována.
6. Vacuum Drying Chyba! Záložka není definována.
7. Insulation Chyba! Záložka není definována.
8. Additional refrigerant Chyba! Záložka není definována.
9. Electrical Wiring Chyba! Záložka není definována.

1. Preface of installation



⚠ Caution

- ✧ The proper design and installation is a critical element of ARV system, installation of piping and electrical works must be carried out by ***suitably qualified, certified professionals*** and in accordance with all applicable legislation.
- ✧ In this service manual, the term “applicable legislation” refers to all national, local and other laws, standard, codes, rules, regulations and other legislation that apply in a given situation.

2. Installation of Outdoor Unit

2.1 Installation Location and Foundation


1. Ensure that the outdoor unit is **installed in a dry, well-ventilated place**.
2. Ensure that the **noise and exhaust ventilation** of the outdoor unit **do not affect the neighbors** of the property owner or any surrounding ventilation.
3. Ensure that the outdoor unit is **installed in a cool place** without direct sunlight exposure or direct radiation of a high-temp heat source.
4. The **outdoor unit** should **be installed** as **close** as possible **to the indoor unit**.
5. The installation location must be **far from waste and oil mist**.
6. The **foundation should be strong enough** to support the outdoor unit.

2.2 Pre tools

Tape measure	Spanner	Electric hammer
		
Screw driver	Nut gasket	Level meter
		


2.3 Maintenance and Ventilation Space

2.3.1 Ensure necessary installation and maintenance space.




2.3.2 If there are **two rows of outdoor units**, we **suggest face to face installation** for easy maintenance, and avoid air short circuit.

2.3.3 If miscellaneous articles are piled around the outdoor unit, it should be **at least 1000mm higher** than the top of outdoor unit. Otherwise, a mechanical discharge device must be added to improve the ventilation.




2.4 Installation of Outdoor Unit

2.4.1 Tighten outdoor unit on mounting support with **M10** bolt and nut, and keep it horizontal. The bolt should have a proper length of 20mm more than base surface.




2.4.2 If the system has more than two outdoor units. The **largest capacity** unit should **be set as the master unit**, while the **others should be set as slave** units, as shown in the

following example.




2.4.3 The installation space for a fixed bolt, please refer to the following drawing.



2.4.4 The foundation can be made of **channel steel or concrete**. **Reserve** the space for **discharging** the condensate **water** from outdoor units.


2.4.5 Install drainage channels to ensure condensed **water flow out** smoothly.



2.4.6 **Don't** use **four-square base** to support outdoor unit.

2.4.7 **Rubber anti-vibration pads** are necessary to avoid **vibration**.

2.4.8 If the outdoor unit need side air flow outlet by a **duct**, it is necessary to **remove** out the wind **grille**.



3. Pipes Laying


3.1 Pre tools

Tube expander	Spanner	Expander
		
Screw driver	Electric hammer	Pipe bender
		
Mounting bracket hanger	Hoop	Expansive bolt
		

3.2 Selection of copper pipe

3.2.1 Please use **seamless red copper pipe**.

3.2.2 **Specification** of refrigerant pipe should be selected according to **unit requirement**



※ Thickness of copper tube

Specifications		Thickness (mm)	Weight / length	
inch	mm		1m =* Kg	1Kg=* m
1/4	Φ 6.35	0.8	0.124	8.06
3/8	Φ 9.52	0.8	0.195	5.12
1/2	Φ 12.7	0.9	0.297	3.36
5/8	Φ 15.88	1.0	0.416	2.4
3/4	Φ 19.05	1.0	0.505	1.98
7/8	Φ 22.22	1.2	0.706	1.41
1	Φ 25.4	1.2	0.813	1.23
	Φ 28.6	1.2	0.92	1.08
	Φ 31.8	1.2	1.11	0.9
	Φ 34.9	1.3	1.223	0.817
	Φ 38.1	1.4	1.438	0.695
	Φ 41.3	1.5	1.671	0.598
	Φ 44.5	1.5	1.823	0.554

3.2.3 If **pipes** will be **stored** for a **long time**, the pipes should be **charged** into **0.2~0.5MPa N2** and the **nozzle** should be **sealed** by welding.




3.2.4 **Don't let dust** such as concrete fragment, sand and copper slag ingress **into the system**;



3.2.5 **Don't install pipe while raining to prevent water ingress**; blocking capillary or expansion valve, generating acid Iron/copper erosion due to refrigerant hydrolysis, generating foreign matter crystal (cage compounds) due to reaction of refrigeration oil

3.3 Accessory bag

Accessory bag in outdoor unit



3.4 Bending of copper tube


3.4.1 **Do not** right angle **bending many times in a short distance**



Larger flow resistance of refrigerant

3.4.2 **Pipe bender must be used** for pipe bending. The curvature can't be too small, otherwise the pipe may be bent and shrunk, affecting refrigerant flow;

3.4.3 **Don't repeat bending** and unbending operation over three times on the same position of pipe (because pipe will be hardened in this way).




3.5 Flaring of copper tube


3.5.1 The **burr** of the copper tube **should be removed** before the copper tube is expanded




3.5.2 It is required to expand the inside diameter at connection area with **Tube expander**





3.5.3 The copper pipe connected to the indoor units needs to be expanded by **Expander**



1~1.5m




Flare pipe with **Expander** as per the dimensions of flaring opening in the following table.


Diameter of pipe	Tightening torque	Machining dimension of	Shape of flaring	Apply oil
1/4in(φ6.35mm)	15-19 (N·m)	8.8-9.1mm		
3/8in(φ9.52mm)	35-40 (N·m)	12.8-13.2mm		
1/2in(φ12.7mm)	50-60 (N·m)	16.2-16.6mm		
5/8in(φ15.88mm)	68-80 (N·m)	19.2-19.6mm		
3/4in(φ19.05mm)	100-120 (N·m)	23.6-24mm		

3.6 Separation Tube (branch joint)


3.6.1 The **branch** joint must be installed **horizontally** and the lean **angel** should be $\leq 15^\circ$ to avoid refrigerant distribution unbalance.



Horizontally




3.6.2 To ensure the refrigerant distribution is balance, pipe length which between two branch joints $\geq 1000\text{mm}$, the straight pipe length after the branch pipe $\geq 500\text{m}$



3.7 Oil Trap

When the Vertical **height** between indoor and outdoor units more than **8 or 10 meters**, ensure the Refrigeration **oil return to compressor** smoothly, the **oil trap is necessary**



3.8 Pipeline fixing

Refrigerant pipe should be fixed, when running, refrigerant pipe will sway, expand or shrink, if unfixed, load will concentrate on certain part, result fracture of refrigerant pipe. The pipe should be fixed **every 1~2m**.




4. Welding

4.1 Pre tools

Nitrogen cylinder	Nitrogen pressure regulating valve	Nitrogen pressure gauge
		
Welding device	Connection hose	
		


4.2 Flushing

Before connection use nitrogen (The pressure of the nitrogen is **0.5 MPa**) or air to **remove dust** and **moisture** inside pipe.




4.3 Fill nitrogen and welding

4.3.1 Ensure to fill nitrogen (The pressure of the nitrogen is **0.02 MPa**) for protection when welding.



4.3.2 It's necessary to **fill nitrogen to prevent** oxidation layer (**Cu_2O**) formed in copper pipe when welding, otherwise substantial oxidation layers will cause blockage of capillary tube or expansion valve, abnormal discharge temperature, poor cooling or heating performance.




4.3.3 If permitted, it's recommended to use ***less indoor units and shorter pipeline***

5. Gas Tightness Test

5.1 Purpose and Steps

To confirm whether there is leakage in pipe by using nitrogen, and the steps are as follows



① Observe pressure drops

It's necessary to correct if pressurized temperature is different from observed ambient temperature with difference of **0.01MPa/1 °C**.

Correction value = (Pressurized temperature - observed temperature) x 0.01

Example:

Pressure is 4.0 MPa and temperature is 25°C in case of pressurization.

After 24 hours, if the pressure is 3.95MPa and temperature is 20°C, it is deemed qualified.

② Check leakage point.

If there is pressure drop but leakage point can't be found in pressure test:

1. Discharge nitrogen until the pressure is **0.3MPa**.

2. Charge R410a refrigerant to **0.5MPa** (namely the mixed state of nitrogen and refrigerant).
3. Check with halogen lamp, butane gas (petroleum gas) detector and electric detector.
4. If leakage point can't be found, recheck by continuously pressurize up to **2.8MPa**.
(maximum pressure is 4.0MPa)


5.2 Pre Test tool

nitrogen cylinder	Nitrogen pressure regulating valve	Nitrogen pressure gauge
		
Soap water (Use of leakage)	Welding device (Use of leakage)	Connection hose
		

5.3 Caution


There is no power for indoor unit's EXV before commissioning, so the EXV is closed, the nitrogen gas unable to flow from A to B or B to A


So when charging the nitrogen gas, ***it should be charged from the both (liquid & gas) sides***




5.4 Schematic diagram

Nitrogen filling mode 1: Connect to gas and liquid cut-off valve



Nitrogen filling mode 2: Connect to main gas & liquid piping

If pressure gauge point drops, apply soap water (*Focus on inspection of welding points, such as 1~8 below*) to check for leakage, Find out the leak point and re weld



6. Vacuum Drying

6.1 Selection of vacuum pump

1. Vacuuming suction must be less than -14.6PSI (756mmHg).
2. The discharge of vacuum pump is over **4L/s**.
3. The precision of vacuum pump is over 0.001ft.H₂O (0.02mmHg)

Note:

1. Under the normal air pressure, the boiling point of water (steam temperature) **is 100 °C**, but the pressure in vacuum pump pipe is near vacuum, this makes the boiling point lower to below the outside air temperature, and the water in the pipe is evaporated.
2. After the vacuuming process of R410A refrigerant circulation system is complete, vacuum pump will stop running. As a result of suction in the air conditioning system, vacuum pump lubricant will seep back into the system. This situation will also occur if vacuum pump suddenly stops during operation. It will cause different oils mix, leading to system malfunction, therefore it is recommended to use one-way valve to prevent reverse flow of oil in vacuum pump.


Water's boiling point (°C)	Pressure (mmHg)	Vacuum degree (mmHg)
40	55	-705
30	36	-724
26.7	25	-735

Manual

24.4	23	-737
22.2	20	-740
20.6	18	-742
17.8	15	-745
15.0	13	-747
11.7	10	-750
7.2	8	-752
0	5	-755


Example: When the ambient temperature is 7.2°C, vacuuming can be carried out under -752mmHg.

6.2 Pre tools

Vacuum pump (4L/s)	vacuum pressure gauge	Connection hose
		

6.3 Schematic diagram

Gas and liquid stop valve must be closed, 1~3 valves should be opened
 Vacuum pump with **one-way valve** to **prevent pump oil** from flowing backward while the vacuum pump is stopped



6.5 Vacuum drying

Connect the pressure gauge to the infusing mouth of gas and liquid pipe



While the vacuum gauge pressure is less than -100.7Kpa, perform the vacuum drying for **more than 1 hour** and closed the valve 2



After vacuum pump stopped, check whether the pressure is maintained within -100.7Kpa for an hour




Over-100.7Kpa



Check for gas leakage



Manual



7. Insulation

7.1 Purpose of Insulation

- Prevent condensate water adhere to the gas pipe
- Protect people from hurt of high temp.
- Avoid energy loss


7.2 Pre tools

Rubber and plastic insulation casing	Cutting knife	Air conditioning bandage
--------------------------------------	---------------	--------------------------



7.3 Caution

7.3.1 The insulation of liquid pipe and gas pipe must be separate



7.3.2 The insulation work must be done to every part of refrigerant pipes



7.3.3 Insulation material

Pipe diameter	Thickness
Φ6.4~15.9mm	≥15mm
Φ15.9~38.1mm	≥20mm
Φ38.1~54.1mm	≥25mm

7.3.4 Thermal insulation wrapping of pipe

Thermal insulation materials should be used for drainage pipe and refrigerant pipe to **prevent condensation or water leakage**.

Note:

- ✧ Wrap refrigerant pipe with thermal insulation materials of good insulation performance ($> 120^{\circ}\text{C}$).
- ✧ Notice for high-humidity environment: the A/C system is verified by condensation conditions test. However, it may subject to dripping if working in high-humidity (condensation temperature $> 23^{\circ}\text{C}$) environment for a long time. In this case, please add the following thermal insulation materials:
- ✧ The thermal insulation materials should be glass fiber thermal insulation materials with 10~20mm thickness.

7.3.5 Sealing of Wall Opening

After installing pipe and drainage pipe, it's necessary to **seal the gap** among wall opening, refrigerant pipe, **drainage** pipe and electric wire with **mortar or putty** to prevent capacity degradation or water leakage caused by rainwater or foreign matter from ingress into room and A/C system.

8. Additional refrigerant

8.1 Calculate refrigerant charge volume

Calculate the required refrigerant volume by the length of liquid pipe → recharge refrigerant.

Pipe size of liquid side (mm)	L1 Φ25.4	L2 Φ22.22	L3 Φ19.05	L4 Φ15.88	L5 Φ12.7	L6 Φ9.52	L7 Φ6.35
Additional refrigerant charge per meter (kg)	0.45	0.34	0.25	0.17	0.11	0.054	0.022


Additional refrigerant charge volume = (L1×0.45) + (L2×0.34) + (L3×0.25) + (L4×0.17) + (L5×0.11) + (L6×0.054) + (L7×0.022)

8.2 Pre tools

Vacuum pump (4L/s)	Connection hose	electronic scale
		
R410A		
		

8.3 Schematic diagram

1. 1~4 # valves all are opened
2. 1#, 3#, 4# valves are opened, 2# valve are closed



8.4 Steps for recharging refrigerant

1. Make sure ***vacuum drying*** is qualified before recharging refrigerant.
2. ***Calculate the required refrigerant volume*** by the diameter and the length of liquid pipe.
3. Use ***electronic scale*** or fluid infusion apparatus to weigh the recharged refrigerant volume.
4. Use soft pipe to connect refrigerant cylinder, pressure gauge, and examine valve of outdoor unit. And recharge in liquid mode. Before recharging, clear the air in the soft pipe and pressure gauge's pipe.


9. Electrical Wiring

9.1 Wiring Diagram of Indoor Unit and Outdoor Unit

Power line must be properly fixed; Outdoor unit must be grounded;

Each indoor unit must be grounded; Power wire must be thickened when it is overlong.

Wiring Diagram of Modular Outdoor Unit




Recommended Specification for Power Line of Outdoor Unit (stand-alone power supply)

Unit Type		Power supply	power line (mm ²)	breaker (A)	leakage current Operate time	ground wire(mm ²)
Separate power	ARV-H250/SR1MV	380~415V 3Ph ~ 50/60Hz	4	32	30mA, < 0.1 sec.	4
	ARV-H280/SR1MV		6	32	30mA, < 0.1 sec.	6
	ARV-H330/SR1MV		6	40	30mA, < 0.1 sec.	6
	ARV-H400/SR1MV		6	50	30mA, < 0.1 sec.	6
	ARV-H450/SR1MV		6	50	30mA, < 0.1 sec.	6

	ARV-H500/SR1MV		10	63	30mA, < 0.1 sec.	10
	ARV-H560/SR1MV		10	63	30mA, < 0.1 sec.	10
	ARV-H610/SR1MV		16	63	30mA, < 0.1 sec.	16

9.2 Communication Wire Connection



9.3 Wiring

9.3.1 Open electric controlled **box cover** of indoor unit, wire according to **electrical schematic diagram** on electric controlled box cover, firmly press connecting wire on connecting terminal without loosening, ground wire must be **connected at designated position**.

9.3.2 Open cover plate of electric appliance on right of outdoor unit and wire according to electrical schematic diagram on backside of electric appliance cover plate.

9.3.3 Make sure to thread connecting wire through tension disc and press firmly, wire end must be **firmly pressed** on connecting terminal without loosening and **ground wire** must be connected at designated position.

Part3 Commissioning

1. Preparatory work..... Chyba! Záložka není definována.
2. Master unit setting Chyba! Záložka není definována.
3. Commissioning Chyba! Záložka není definována.
4. Parameter Setting (Main PCB)..... Chyba! Záložka není definována.
5. Commissioning Based on Monitoring Software .Chyba! Záložka není definována.
6. IDU Parameter setting by Controller Chyba! Záložka není definována.

1. Preparatory work

1.1 Inspection and confirmation

- Confirm that **refrigeration piping and communication** wire of indoor and outdoor units have been connected to the same refrigeration system in order avoid unnecessary malfunctions.
- Confirm **power voltage** is within $\pm 15\%$ rated voltage.
- Confirm that the **power wire and control wire** are correctly connected
- Confirm **wired controller** is properly connected.
- Confirm all units have passed **nitrogen** pressure-keeping test for **24 hours**.
- Confirm the system has been carried out **vacuum drying** and charged with refrigeration as required.

1.2 Preparation before start up

- Turn on power switches of outdoor unit in advance, and keep connected for a **minimum of 6 hours** to ensure refrigerant oil is sufficiently heated.
- **Turn on all valves**. If valves are not fully open unit may be damaged.
- All dial **switches** of indoor / outdoor units have been **set according to the technical requirements**.


1.3 Inspection list of trial run

- Confirm the **fan** impeller is rotating according to its intended route and turns smoothly.
- Check for abnormal **noise** during operation of refrigerant system and compressor.

- Confirm **drainage** is smooth and its lift pump is operational.
- Confirm operating **current** is within the allowed range.
- Confirm each **operating parameter** is within the range permitted by the equipment.

1.4 Refrigerant leakage caution

This air conditioner adopts R410A as refrigerant, which is safe and noncombustible. R410A critical thickness: 0.3kg/m^3 (Critical thickness: the max thickness of Freon without any harm to person).




Calculate the critical thickness through following steps, and take necessary actions.

- 1) Calculate the refrigerant charge volume A, $A = \text{factory charge volume} + \text{additional charge volume}$
- 2) Calculate the indoor area volume (B) (as the minimum volume)

3) Calculate the refrigerant thickness, $A/B \leq \text{critical thickness } 0.3\text{kg/m}^3$.

2. Master unit setting



1	2	Definition
OFF	OFF	Master
OFF	ON	Slave 1
ON	OFF	Slave 2
ON	ON	Slave 3

SW1

OFF OFF

ON

1 2

SW1

OFF ON

ON

1 2

Master unit

AUX

16HP

Slave unit

AUX

12HP

3. Commissioning

IDU and ODU power on, then the main *PCB digital tube displays* “”, it means the system is *waiting for commissioning*

3.0 Enter Commissioning



- **Enter**

Long press “**Fun**” button for *more than 5 s*

- **Exit**


Long press “**Test**” button for *more than 5 s*.

- **Quick finish**

After completing Step “3”, long press “**Fun**” + “**Test**” buttons for *more than 5 s* to complete project commissioning in advance

3.1 Address Setting

Digital tube will display “**1.0.0.0.0**”



Press “**Up**” or “**Down**” buttons to choose 0 or 1

Short press “**Fun**” to confirm


If *manual addressing* is chosen, digital tube will **display** “**1.0.0.0.0**” (the indoor unit’s address should be set by remote controller or wired controller.)

If *automatic addressing* is chosen, digital tube will **display** “**1.0.0.0.1**”

About 2 s later, **enter step 2**.

3.2 Quantity of ODU

Digital tube displays “**2.2.2.2**”




If display **quantity of ODU is inconsistent**, need to conduct manual check (DIP address, communication cable and etc.) and commissioning confirmation again.

If display **quantity of ODU is consistent**, short press “**Fun**” button **to confirm**, digital tube will **display** “**2.2.2.1**” ,

About 2 s later, **enter step 3**.

3.3 Quantity of IDU

Digital tube displays “**3.2.2.16**”




If display **quantity of IDU is inconsistent**, need to conduct check (power and communication cable of indoor units, and etc.) commissioning confirmation again.

If display **quantity of IDU is consistent**, short press “**Fun**” button to confirm. digital tube will **display** “**3.2.2.16**” ,

About 2 s later, **enter step 4**.

3.4 Communication of ODUs

Automatically detects the **communication** between **master main PCB** and **drivers** (fan motor and compressor), after 2 s



If there is **a faulty**, it will **display** “**4.8.8.8.3**”, all buttons are invalid, **need to do Troubleshooting**, if it is **normal**, it will **display** “**4.3.8.8.8**”


Then **detects** indoor and outdoor unit's **capacity ratio**, if it is **out of range**, **display** “**4.8.8.8.3**” **need to do Troubleshooting**. If ratio is **normal**, it will **display** “**4.3.8.8.8**”

About 2 s later, **enter the step 5**.

3.5 Components of ODUs

Automatically **detect components** of outdoor units,

During detecting, display “**5.8.8.8.8**”



If **abnormal**, then corresponding **failure displays**, for example, “**5.8.8.8.4**”

It cannot enter the next judgment


Only **displays** the **fault** with the **highest priority**. In case that several modules had faults, displays the fault codes in turn by address order.

If there are **no** any **faults** or all faults were solved, digital tube displays “**5.8888**”

About 2 s later, **enter step 6**.

3.6 Components of IDUs

During detecting, digital tube displays “**6.8888**”




- If one of indoor units occur **a fault**, display “**6.8888**” **need to do Troubleshooting**

All buttons are invalid

- If there are **no** any **faults** or all faults were solved, digital tube displays “**6**” ,
About 2 s later, **enter step 7**


3.7 Compressor preheating

- If the outdoor unit has been continuously energized for **more than 6 hours**,
displays “**7**” , 2 s later, **enter step 8**.
- Otherwise display “**7436**”, Short press “**Fun**” button, **can skip waiting** and **enter step 8**



3.8 Refrigerant judgment

During detecting, display “**B.**”



- If any [**module low pressure P s**] $\leq -25\text{ }^{\circ}\text{C}$, then point out refrigerant lack protection, display “**B. 5**”
All buttons are invalid
It required to check is there any leakage, need to do air tightness test , maintenance, vacuuming, add refrigerant and do commissioning again
- If it is **normal**, display “**B.**” ,
About 2 s later, **enter step 9.**

3.9 Status judgment

The status judgment of outdoor unit valve “**9.**” , 2sec later, enter the next step.

3.10 Start commissioning

Automatically select operating mode according to outdoor environment temperature

If temperature $\geq 20\text{ }^{\circ}\text{C}$, running cooling model

If temperature $< 20\text{ }^{\circ}\text{C}$, running heating model

This step, displays “**10.**” , waiting for start commissioning. Press “**Fun**” button to start cooling or heating operation test

3.11 Cooling Operation

Display “**16.000**”, all indoor units run in **16 °C & high speed**

If there is a **fault**, displays’ **Err**’ and fault code, like “**ErrF3**”, **need to do troubleshooting** and commissioning again

If there is **no any fault**, 20min later, displays “**16.000**”

After 5s, **enters normal standby status** “**16.006**” or locking “**LoC**”

Project commissioning is finished

3.12 Heating Operation

Display “**30.000**”, all indoor units run in **30 °C & high speed**



If there is **no any fault**, 20min later, displays “**30.000**”,

After 5s, **enters normal standby status** “**30.006**” or locking “**LoC**”.

Project commissioning is finished.

4. Parameter Setting (Main PCB)

4.1 Functions set by switch

Function setting- SW4			1	2	Function	3	Function
			OFF	OFF	Without Compressor emergency(Default)	OFF	Without Modular emergency(Default)
			OFF	ON	1# Compressor emergency	ON	Modular emergency
			ON	OFF	2# Compressor emergency		
			ON	ON	/		
Function setting- SW5			1	2	Function		
			OFF	OFF	Without quiet mode(Default)		
			OFF	ON	Quiet in night		
			ON	OFF	Quiet mode		
			ON	ON	Strong mode		
3	4	Function	5	6	Function	7	8
OFF	OFF	First-ON (Default)	OFF	OFF	static pressure 0 Pa(Default)	Reserve	
OFF	ON	Heating priority	OFF	ON	20 Pa		
ON	OFF	Cooling priority	ON	OFF	50 Pa		
ON	ON	Majority rule	ON	ON	80 Pa		

Notice :

- In the table “**OFF**” means switch to down, “**ON**” means switch to up.
- When you want to change any set, please consult our factory first.
- When you set **Compressor or modular emergency**, please close the Gas/Liquid valve of the ODU, and solve the problem **within 24-48h**, because the emergency cannot work

long time. After solved the problem, please cancel emergency setting, others the ODU cannot run.

4.2 Parameter set by Key button

4.2.1 General introduce

After commissioning, the system is standing-by.

1st step--- Press “**Fun**” key for 2 s, the Main digital tube will displays as below:

1. 【Parameter Checking“**E**88888” (flash) 】 、
2. 【Function Setting “**P**88888” (flash) 】 、
3. 【Parameter Setting“**L**88888” (flash) 】 、
4. 【Commissioning “**d**88888” (flash) 】 、
5. 【Restore to factory setting“**r**88888” (flash) 】

2st step---Press “**Up**” or “**Down**” key to choose [**E**]or [**P**] or [**d**] or [**r**]

3st step---Press “**Fun**” to confirm

Sketch Map:

		1st: Press “Fun” 2 s		2st: ”Up” or ”Down” to choose below		3st : Press “Fun” to confirm			
									
Commissioning		Status		Checking		Parameter Checking		Restore to factory setting	


4.2.2 [E] Parameter Checking

Choose “**E0000**”, press “**Fun**” key

1. Press “**Up**” or “**Down**” key to choose the number of function you want (**1~15**)
2. Then press “**Fun**” to display

For example : Digital tube displays like **1.640**, means **frequency of 1# comp is 64 rps**

Sketch Map:

		1 means :			
		Frequency of 1# comp			
		64 means:			
		1# compressor's running frequency is 64 rps			
		To Check other statue information by			
		Press “ up ”/” down ”, display from 1~ 15			
No	parameter name	units	No	parameter name	units
1	Frequency of 1# comp	rps	9	ODU environment temp.	0.1℃
2	Frequency of 2# comp	rps	10	Suction temp.	0.1℃
3	Open degree of PMV1	pls	11	Tci1(outlet of condenser 1)	0.1℃
4	Open degree of PMV2	pls	12	Tci1(outlet of condenser 2)	0.1℃
5	High press sensor-Temp.	0.1℃	13	Tdef1(defrost temperature)	0.1℃
6	Low press sensor-Temp.	0.1℃	14	Tdef2(defrost temperature)	0.1℃
7	Dis-Temp. of 1# comp	0.1℃	15	Edition of procedure	/

8	Dis-Temp. of 1# comp	0.1℃			
---	----------------------	------	--	--	--

4.2.3 [P] Present Function Checking

Choose “**P**” , and press “**Fun**” key

1. Press “**Up**” or “**Down**” key to choose the number of function you want (1/3/4/6)

For example : Digital displays like “**P**” (P-light, 1-Flash)

2. Then press “**Fun**” to display

For example: display a parameter like “**135**”, means the present max capacity rate of IDU/ODU (No 1) is **135%**

Serial Number	Function Name	Display
1	IDU/ODU capacity rate	135 or 200 [135: Rate is135%] [200: Rate is200%]
3	VER (variable energy-efficiency regulation)	0 or 1 or 2 [0 : basic mode] [1 : high efficiency] [2 : turbo mode]
4	Blow off snow (Auto snow-blowing)	0 or 1 or 2 or 3 or 4 [0 : without this function] [1 : 0.5h Cycle time] [2 : 1h Cycle time] [3 : 3h Cycle time] [4 : 10h Cycle time]
6	Economic locking (26℃)	0 or 1 [0 : without this function] [1 : lock 20/26℃]

4.2.4 [C] Function Setting

Choose “”, short press “**Fun**” key

1. Press “**Up**” or “**Down**” key to choose the number of function you want (1~8)

For example : Digital displays “” (C-light,1-flash)

2. Then **press “Fun” key to enter** the setting.
3. Change the setting by pressing “**Up**” or “**Down**” key
4. Short press “**Fun**” key to confirm

The function name and number show in the table below.

Function names	1 st step	2 nd step	3 rd step	Notice
	Main menu	Serial Number	Parameter Setting	
IDU/ODU capacity rate		1	135 : IDU/ODU≤135% 200 : IDU/ODU≤200%	1. Choose the number [1] 2. Short press [Fun] 3. Choose [135] or [200] 135 is default , when you change it , it will influence the comfort , please consult our factory first.
Clean (Auto dust removal)		2	/	1. Choose the number [2] 2. Short press [Fun] , 1 time effective Then outdoor fan will run immediately

VER (variable energy- efficiency regulation)		3	0 : basic mode 1 : high efficiency 2 : turbo mode	1. Choose number [3] 2. Short press [Fun] 3. choose [0] or [1] or [2] 0 is default, when you change it ,it will influence the comfort or power consumption
Blow off snow (Auto snow blowing)		4	0 : No this function 1 : 0.5h (cycle time) 2 : 1h (cycle time) 3 : 3h (cycle time) 4 : 10h (cycle time)	1. Choose the number [4] 2. Short press [Fun] 3. Choose [0] or [1] or [2] or [3] or [4] 0 is default, when you change it ,the outdoor fan will run to blowing off snow automatically and cycle by cycle
Vacuum Pumping		5	/	1. Choose the number [5] 2. Short press [Fun] , 1 time effective Then ODU will be ready for Vacuum pumping
Economic locking (26℃)		6	0 : No this function 1 : lock 20/26℃	1. Choose number [6] 2. Short press [Fun] 3. choose [0] or [1] 0 is default, when you change it , the IDU setting temperature will be locked at 20 ℃ in heating mode and 26 ℃ in cooling mode
Refrigerant recycle		7	/	1. Choose the number [7] 2. Short press [Fun] , 1 time effective Then Recycle refrigerant to ODU

Refrigerant charging		8	/	1. Choose the number [8] 2. Short press [Fun] , 1 time effective Automatically determine whether the refrigerant is filled up (by detecting pressure) requires
----------------------	--	---	---	---

4.2.5 [r] Restore to Factory Setting

Choose “**EEEE**”, short press “**Fun**” key

1. Press “**Up**” or “**Down**” key to choose the number of function you want **(1~3)**

[1]: Control parameter be restored to factory default

[2]: Control parameter, running storage parameter are restored to factory default

[3]: Control parameter, running storage parameter, commissioning storage parameter are restored to factory default

2. Press “**Fun**” key to confirm

5. Commissioning Based on Monitoring Software

5.1 General Information


1. Main Function

1.1 Used for **monitoring** indoor and outdoor units' **operation parameters** , check the refrigerant system is normal or not

1.2 **Control** indoor units' **operation state** (temperature setting, fan speed, ON/OFF, operation mode...)

1.3 Operation parameters and curve can **be saved** as a *data base file*

2. Installation Diagram





5.2 Accessory

1. Hardware


Laptop	USB to RS485 converter
	

2. Software


Monitoring Software	Driver Program
 Setup_EN_1.0.1. 0	 AUX ARV6 monitor driver

5.3 Installation of software


1. Double click




2. Choose the installation path, then click “**Next**”




3. Confirm the installation path, then click “**Next**”



4. Choose “**Create a desktop shortcut**” and “**Create a quick launch shortcut**”, then click “**Next**”




5. Confirm, click "**Install**"




6. Install... waiting


Manual




7. Automatic judge install "Microsoft .net Framework 4.0" or not , If it should be installed , please choose ***"I have read and accept the license terms."*** then click ***"Install"***



8. Install "Microsoft .net Framework 4.0" , waiting...



9. Finishing



10. Finish the installation


Desktop Icon




5.4 Installation of Driver

1. Installation steps


1. After USB to RS485 converter be connect to laptop's "**USB port**", Open Management->Other devices-> "**FT232R_USB_UART**".




2、 Choose "**FT232R_USB_UART**" right click, then choose "**Update Driver Software**"




3、 Choose and click "**Browse my compute for driver software**"




4、 Choose the position of the Driver program , Click "**OK**", then "**Next**"




5、 Finish installation of the first part




6、Open Management->Other devices-> ***“USB Serial Port”*** right click, then choose ***“Update Driver Software”***



7、 Choose the position of the Driver program , Click **"OK"** , then **"Next"**



8、 Finishing installation




2. Check USB-485 COM

1. Open the device manager


(**Win 7 path is:** Control Panel > device manager; **Win XP path is:** Control Panel > management tool > Computer Management > device manager. The following Win 7 system is taken as an example)

2. Click " **COM**" can check the USB-485 port "USB Serial Port(**COM** x) "




3. Change USB-485 COM


1. Choose the "**USB serial port**", Choose "**attribute**" by right mouse button



2. Click "**port setting**", then choose "**Advanced**" by left mouse button




3. Through "**COM port**" choose a "**COM x**", then click "**OK**" to finish change




5.5 Function

1. Communication Port

1. Click “**Connect**” button





2. Choose “**Com**”, then click “**Submit**” to start



2. Data Frame

1. Click “**Listen(L)**” button, Choose “**Frame date**”



3. Control Indoor Unit

Click “**indoor control**” button, Pop-up the following window

Central air-conditioning debugger

Communicate(C) Listen(L) Control(S) Data(D) Replay(R) Curve(P) Help(H)

Connect... Stop connect Indoor control Start Pause Stop Exit

Address: 8 DriveCmd: Cooling ON_OFF: ON SwingCmd: ON Tai: 26.4

Unit mode: Ducted unit-2 CapReq: Off ModeCmd: Cooling HealthCmd: OFF Te2: 24.4

Capacity: 5.0 Cap(%): 0 Settemp: 16.0 HeaterCmd: OFF Tem: 25.0

FirmwVer: V3.7 PC Ctrl: YES FanCmd: Auto SleepCmd: OFF Te1: -55.0

Address	Capacity	ON_OFF	ModeCmd	Settemp	FanCmd	DriveCmd	CapReq	Cap(%)	Tai	Te2	Tem	T
1	4.0	ON	Ventilation	28.0	Low	Stop	Off	0	25.5	21.3	21.6	2

Wired controller

Indoor units' IP address

Indoor control

Temperature set

16 °C

High

Sleep Fan Swing Mode

Func OFF Health


Choose all Cancel all

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32
33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48
49	50	51	52	53	54	55	56
57	58	59	60	61	62	63	64

4. Operation Parameter Information

1. “**Outdoor data(1/2)**” means: The system had **2 ODUs**, **1 unit was running** and **another unit was standby**

“**Indoor data(3/11)**” means: The system had **11 IDUs**, **3 units were running** and **8 units were standby**



Variable name	Master	Slave1
RatedCap[kW]	61.5	45.0
OperMode	Cooling	Cooling
OperProc	Stop	Common
Priority	1	0

2. Whole outdoor data interface

Manual

The screenshot shows the 'Central air-conditioning debugger' software interface. It features a menu bar (Communicate(C), Listen(L), Control(S), Data(D), Replay(R), Curve(P), Help(H)), a toolbar with buttons like 'Connect', 'Stop connect', 'Indoor control', 'Start', 'Pause', 'Stop', and 'Exit', and tabs for 'Outdoor data(1/2)' and 'Indoor data (3/11)'. The main area displays three tables of data, each highlighted with a red box and a circled number:

- Table 1 (Outdoor info):** Lists variables like Pd[bar], Ps[bar], Pd_t[°C], Ps_t[°C], Tda[°C], Tdb[°C], Toil[°C], Ts[°C], Tao[°C], Tci[°C], Tdef1[°C], Tgi[°C], Tgo[°C], Tlo[°C], Tfin1[°C], Tfin2[°C], SCS[SHS][°C], HPS 1, and PC control, with Master and Slave1 values.
- Table 2 (Variable name):** Lists variables like INV1[rps], INV2[rps], alINV1[rps], alINV2[rps], Fan1Tar[rpm], Fan2Tar[rpm], Fan1Spd[rpm/grade], Fan2Spd[rpm/grade], Pulse_EXV 1[pls], Pulse_EXV 2[pls], Pulse_EXV 3[pls], 4WV, SV1, SV2, SV3, SV5, SV6, SV7, and E-heater 1, with Master and Slave1 values.
- Table 3 (Variable name):** Lists variables like RatedCap[kW], OperMode, OperProc, Priority, TarCap[kW], RunCap[kW], OutRatio[%], Run[stop time[s], Error code, V_Inverter 1[V], ACI1[A], Icompa[A], V_Inverter 2[V], ACI2[A], Icompb[A], Ifan1[A], Ifan2[A], INV info, and FirmwVer, with Master and Slave1 values.

Below the tables, there is a 'Main machine info' section showing unit mode (ARV 6), operating mode (Cooling), and other parameters. A 'Communicate data' section shows received data packets. The status bar at the bottom indicates 'Status: Realtime monitor', 'Remote IP: 10.2.116.12, Port: 10001', and 'Database path: C:\AuxData\'. The bottom right corner shows 'Error info'.

NO. ①	Name	Detailed information	Reference
	P _d [bar]	Discharge pressure (1bar=0.1Mpa)	< 32bar
	P _s [bar]	Suction pressure (1bar=0.1Mpa)	< 10bar
	P _{d_t} [°C]	Saturation temp. (discharge pressure)	/
	P _{s_t} [°C]	Saturation temp. (suction pressure)	/
	T _{da} [°C]	Discharge temp. (1# Compressor)	< 92°C
	T _{db} [°C]	Discharge temp. (2# Compressor)	< 92°C
	T _{oil} [°C]	Oil temp.	/
	T _s [°C]	Suction temp.	< 22°C
	T _{ao} [°C]	Outdoor ambient temp.	/
	T _{ci1} [°C]	Outlet temp. of condenser	< 45°C
	T _{def1} [°C]	Defrost temp.	< 45°C
	T _{gi} [°C]	Outlet temperature of PMV3	/

Manual

Variable name	Master	Slave1			
INV2[rps]			INV2[rps]	Target frequency (2# Compressor)	/
INV1[rps]	0.0	67.0	aiNV1[rps]	Running frequency (1# Compressor)	/
INV2[rps]	0.0	0.0	aiNV2[rps]	Running frequency (2# Compressor)	/
aiNV1[rps]	0.0	67.0	Fan1Tar	Target rpm (1# motor)	/
aiNV2[rps]	0.0	0.0	Fan2Tar	Target rpm (2# motor)	/
Fan1Tar[rpm]	0	1005	Fan1Spd	Running rpm (1# motor)	/
Fan2Tar[rpm]	0	1005	Fan2Spd	Running rpm (2# motor)	/
Fan1Spd[rpm/grade]	0	1005	Pluse_EXV1	Pluse_EXV1 (heating)	480(cooling)
Fan2Spd[rpm/grade]	0	1005	Pluse_EXV2	Pluse_EXV2 (heating)	480(cooling)
Pulse_EXV 1[pls]	0	480	Pluse_EXV3	Pluse_EXV3(sub-cooling)	/
Pulse_EXV 2[pls]	0	480	4WV	4-way valve (heating)	Close(cooling)
Pulse_EXV 3[pls]	0	87	SV1	Unloading valve	/
4WV	Close	Close	SV2	/	/
SV1	Close	Close	SV3	Sub-cooling valve	Open(cooling)
SV2	Close	Close	SV5	Vapor injection valve (1# Comp.)	Open(heating)
SV3	Close	Open	SV6	Vapor injection valve (2# Comp.)	Open(heating)
SV5	Close	Close	SV7	/	/
SV6	Close	Close	E-heater1	Preheating (1# Compressor)	/
SV7	Close	Close	E-heater1	Preheating (2# Compressor)	/
E-heater 1	Close	Close			

NO. ③	Name	Detailed information	Reference
-------	------	----------------------	-----------

Manual

Variable name	Master	Slave1	Rated Cap [kW]	Outdoor capacity	Nameplate
RatedCap[kW]	61.5	45.0	Oper Mode	Operating Mode	/
OperMode	Cooling	Cooling	Oper Proc	Operating process state	Oil return/Comm
OperProc	Stop	Common	Priority	Priority	1/0
Priority	1	0	TarCap	Target output capacity	0~100
TarCap[kW]	0.0	24.2	RunCap	Running output capacity	0~100
RunCap[kW]	0.0	24.1	OutRatio	Target output capacity/ Outdoor capacity	/
OutRatio[%]	0.000	53.600	Run/Stop	Running time	/
Run stop time[s]	01:08:37	01:05:17	Error Code	Error Code	/
ErrorCode	00	00	V_Inverter1	Busbar voltage (1# Compressor)	512
V_Inverter 1[V]	512	502	ACI1[A]	1# Drive module current input	
ACI1[A]	0.0	0.0	Icompa[A]	Current (1# Compressor)	Nameplate
Icompa[A]	0.0	24.2	V_Inverter2	Busbar voltage (2# Compressor)	512
V_Inverter 2[V]	513	0	ACI2A]	2# Drive module current input	
ACI2[A]	0.0	0.0	IcompbA]	Current (2# Compressor)	Nameplate
Icompb[A]	0.0	0.0	Ifan1[A]	Current (1# Fan Motor)	Nameplate
Ifan1[A]	0.0	2.0	Ifan2A]	Current (2# Fan Motor)	Nameplate
Ifan2[A]	0.0	1.8			
INV info	0	0			
FirmwVer	V1.1	V1.1			

Manual

3. Whole Indoor data interface

Central air-conditioning debugger

Communicate(C) Listen(L) Control(S) Data(D) Replay(R) Curve(P) Help(H)

Connect... Stop connect Indoor control Start Pause Stop Exit

Outdoor data(1/1) Indoor data (4/6)

Address 1 DriveCmd: Cooling ON_OFF: ON SwingCmd: OFF Tai: 24 SHS: 4 Pump: NO FloatSW: Open WCAAddr: 1
 Unit mode: Ducted unit-2 CapReq: On ModeCmd: Cooling HealthCmd: OFF Te2: 18 SCS: 0 Heater: NO Room card: Open CCAddr: 64
 Capacity: 0.8 Cap(%): 13 Settemp: 16 HeaterCmd: OFF Tem: 14 Pulse_EXV: 40 Health: NO Switch: Close Prot_C&H: NO
 FirmwVer: V1.3 PC Ctrl: YES FanCmd: High SleepCmd: OFF Te1: 19 Fan speed: High Swing: NO Slient: NO Errorcode: 00

Address	Capacity	ON OFF	ModeCmd	Settemp	FanCmd	DriveCmd	CapReq	Cap(%)	Tai	Te2	Tem	Te1	SHS	SCS	Pulse_EXV	Fan speed	ErrorCode	Pump	Heater	Health	Swing	Room
1	0.8	ON	Cooling	16	High	Cooling	On	13	24	18	14	19	4	0	40	High	00	NO	NO	NO	NO	NO
2	2.5	ON	Cooling	16	High	Cooling	On	13	24	18	14	19	4	0	60	High	00	NO	NO	NO	NO	NO
3	0.8	ON	Cooling	16	High	Cooling	On	13	25.5	18	14	21	2	0	480	High	00	YES	NO	NO	NO	NO
4	0.8	ON	Cooling	16	High	Cooling	On	13	25.5	18	14	21	2	0	480	High	00	YES	NO	NO	NO	NO
5	0.8	OFF	Cooling	16	High	Stop	Off	0	24	18	14	19	0	0	0	Stop	00	NO	NO	NO	NO	NO
6	2	OFF	Cooling	27	Medium	Stop	Off	0	24	18	14	19	0	0	0	Stop	00	NO	NO	NO	NO	NO

Choose a line(one of the indoor unit), then the **detailed information** of this indoor unit **will be displayed** above this line (① & ②)

Central air-conditioning debugger

Communicate(C) Listen(L) Control(S) Data(D) Replay(R) Curve(P) Help(H)

Connect... Stop connect Indoor control Start Pause Stop Exit

Outdoor data(1/1) Indoor data (4/6)

Address 4 DriveCmd: Cooling ON_OFF: ON SwingCmd: OFF Tai: 25.5 ①
 Unit mode: Ducted unit-2 CapReq: On ModeCmd: Cooling HealthCmd: OFF Te2: 18
 Capacity: 0.8 Cap(%): 13 Settemp: 16 HeaterCmd: OFF Tem: 14
 FirmwVer: V4.5 PC Ctrl: NO FanCmd: High SleepCmd: OFF Te1: 21

SHS: 2 ② Pump: YES FloatSW: Close WCAAddr: 1
 SCS: 0 Heater: NO Room card: Open CCAddr: 64
 Pulse_EXV: 480 Health: NO Switch: Close Prot_C&H: NO
 Fan speed: High Swing: NO Slient: NO Errorcode: 00

Address	Capacity	ON OFF	ModeCmd	Settemp	FanCmd	DriveCmd	CapReq	Cap(%)	Tai	Te2	Tem	Te1	SHS	SCS	Pulse_EXV	Fan speed	ErrorCode	Pump	Heater	Health	Swing	Room
1	0.8	ON	Cooling	16	High	Cooling	On	13	24	18	14	19	4	0	40	High	00	NO	NO	NO	NO	NO
2	2.5	ON	Cooling	16	High	Cooling	On	13	24	18	14	19	4	0	60	High	00	NO	NO	NO	NO	NO
3	0.8	ON	Cooling	16	High	Cooling	On	13	25.5	18	14	21	2	0	480	High	00	YES	NO	NO	NO	NO
4	0.8	ON	Cooling	16	High	Cooling	On	13	25.5	18	14	21	2	0	480	High	00	YES	NO	NO	NO	NO
5	0.8	OFF	Cooling	16	High	Stop	Off	0	24	18	14	19	0	0	0	Stop	00	NO	NO	NO	NO	NO
6	2	OFF	Cooling	27	Medium	Stop	Off	0	24	18	14	19	0	0	0	Stop	00	NO	NO	NO	NO	NO

NO. ①

Central air-conditioning debugger

Communicate(C) Listen(L) Control(S) Data(D) Replay(R) Curve(P) Help(H)

Connect... Stop connect Indoor control Start Pause Stop Exit

Address 4 DriveCmd: Cooling ON_OFF: ON SwingCmd: OFF Tai: 25.5
 Unit mode: Ducted unit-2 CapReq: On ModeCmd: Cooling HealthCmd: OFF Te2: 18
 Capacity: 0.8 Cap(%): 13 Settemp: 16 HeaterCmd: OFF Tem: 14
 FirmwVer: V4.5 PC Ctrl: NO FanCmd: High SleepCmd: OFF Te1: 21

Name	Detailed information	Reference
Address	Indoor unit IP address	
Unit Mode	Type of indoor unit	
Capacity	Indoor unit's capacity	Nameplate
FirmwVer	/	
DriveCmd	Drive mode state	
CapReq	Demand state	
Cap(%)	Capacity ration	
PC Ctrl	/	
ON_OFF	ON/OFF state	
ModeCmd	Setting Mode	
Settemp	Setting temperature	
FanCmd	Setting fan speed	
SwingCmd	Setting swing mode	
HealthCmd	Health mode	
HeaterCmd	Electric auxiliary heat mode	
SleepCmd	Sleep mode	
Tai	Room temperature	
Te2	Inlet temperature of evaporator	
Tem	Mid temperature of evaporator	
Te1	Outlet temperature of evaporator	


NO. ②

						Outdoor data(1/1)		Indoor data (4/6)		
SHS: 2						Pump: YES		FloatSW: Close		WCAddr: 1
SCS: 0						Heater: NO		Room card: Open		CCAddr: 64
Pulse_EXV: 480						Health: NO		Switch: Close		Prot_C&H: NO
Fan speed: High						Swing: NO		Slient: NO		ErrorCode: 00
1	SHS	SCS	Pulse_EXV	Fan speed	ErrorCode	Pump	Heater	Health	Swing	Room card
9	4	0	40	High	00	NO	NO	NO	NO	0
9	4	0	60	High	00	NO	NO	NO	NO	0
1	2	0	480	High	00	YES	NO	NO	NO	0
1	2	0	480	High	00	YES	NO	NO	NO	0
9	0	0	0	Stop	00	NO	NO	NO	NO	0
9	0	0	0	Stop	00	NO	NO	NO	NO	0


Name	Detailed information	Reference
SHS	Super-heat	
SCS	Sub-cooled	
Pulse_EXV	Pulse_EXV	100~300
Fan speed	Fan speed state	
Pump	Pump	
Heater	Electric auxiliary heat	
Health	Health	
Swing	Swing	
FloatSW	Float switch state	
Room card	Room card state	
Switch	/	
Slient	Slient mode	
WCAddr	Wired controller address	
CCAddr	Central controller address	
Prot_C&H	Protect of super-heat state	
Error code	Error code	

5. Operation Parameter Save


1. Click “**Data**” button



2. Choose “**Data save setting**” button




3. Choose “**Raw Data save setting**” button




6. Operation Parameter Replay


1. Click “**Replay(R)**” button, choose a data file to replay



2. Click “**Start**” button to replay




3. Replay progress, replay time, data path were displayed at the bottom.



7. Operation Parameter Curve


1. Click “**Curve(P)**” button



2. **The curve**


Can show all parameters which changing according the time

Can read the real time parameters within recent 30 min



8. Operation Manual

1. Click "**Help(H)**" button ,then choose "**Help**" to open the operation manual



5.5 Registration


1. Permission Description

The software's default state is the unregistered which can **read real-time parameter, operation data's save, indoor units' control, operation parameter's curve**


Parameter data **replay** function **need to be registered**, otherwise, cannot replay data

2. Registration Steps

1. Click "**Help(H)**" button to choose "**Generate raw code**",




2. Click "**Generate**"



3. **Copy raw code**, then **send to technical** support engineer


4. Technical support engineer **provide registration code**

5. Click "**Help(H)**" button to choose "**Register**"



The screenshot shows the 'Central air-conditioning debugger' application. The menu bar includes 'Communicate(C)', 'Listen(L)', 'Control(S)', 'Data(D)', 'Replay(R)', 'Curve(P)', and 'Help(H)'. The 'Help(H)' menu is open, displaying options: 'Generate raw code...', 'Register...', 'Remote connect...', 'Export tool...', 'Help', and 'About'. The 'Register...' option is highlighted. The main window has a tab labeled 'Outdoor info'.

5. Input the Register and finish



The screenshot shows the same application with the 'Register' dialog box open. The dialog box has a title bar 'Register' and a text area containing the register code: 'of33coZXjSqbS1YpGQlv5/XRX+YKNonoz1XXJS3LWtRply6kJy5y0dJiWzoYj427wnUvvgqbmO4mhGEDIN5HhC93HohyFh/iVqEuYzD3C5A='. At the bottom of the dialog are 'Submit' and 'Cancel' buttons. The background application shows the 'Help(H)' menu closed and the 'Outdoor info' tab selected.

6. IDU Parameter setting by Controller

6.1 Parameter Setting Items

No.	Parameter Setting Items	Default value	Min. value	Max. value	Remark
1	Communication ID address	1	1	64	
2	Centralized ID address	1	1	64	
3	wired controller ID address	1	1	16	
4	model of indoor unit	1	0	35	01 :50HZ Low ESP Duct (<i>Drain Pump</i>) 01 :Mid ESP Duct (<i>Drain Pump</i>) 02 :High ESP Duct (<i>Within 60K</i>) 02 :High ESP Duct (<i>2 Pipes systems, 22.28.45.54kw</i>) 10 :Cassette Unit C7 Type (<i>09-18K</i>) 10 :DC Cassette Unit E Type (<i>09-18K</i>) 11 :DC Cassette Unit (<i>24-48K,MB12</i>) 12 :DC Mid ESP Duct 13 :Ceiling & Floor Unit 22 :Fresh Air Processor (<i>1 pipe system, 22.28kw</i>) 23 :AHU 24 :Mid ESP duct (<i>Optional Drain Pump</i>) 24 :60HZ low ESP duct (<i>Drain Pump</i>) 24 :DC low ESP duct (<i>Drain Pump</i>) 24 :AC low ESP duct (<i>Optional Drain Pump</i>) 26 :DC E type Low ESP Duct 28 :One way cassette 30 :Two way cassette 32 :Wall - Mounted (<i>L Type</i>) 34 :Fresh Air Processor (<i>2 Pipe system, 22.28kw</i>) 35 :High ESP Duct (<i>1 Pipe system, 22.28kw</i>)
5	capacity of indoor unit	8	1	100	280W/unit

Manual

6	priority of indoor unit	0	0	3	0--No priority 1--priority 1 2--priority 2 3--priority 3
7	selection of room silent mode	0	0	1	0--normal 1--silent mode
8	auto restart function of indoor unit	1	0	1	0—Available 1--not available
9	room card selection	0	0	1	0--invalid room card 1--valid room card
10	clearing time of filter net	5	1	5	500h/unit
11	operating mode displayed by wired controller	1	0	2	0--[auto][heating] [dehumidification][cooling][ventilation] 1--[heating] [dehumidification][cooling][ventilation] 2-- [dehumidification][cooling][ventilation]
12	installation height of indoor unit	0	0	1	0-- installation height is lower than 2.7m 1--installation height is higher than 2.7m
13	switching between Celsius degree and Fahrenheit	0	0	1	0--Celsius degree 1--Fahrenheit
14	display of room temperature	0	0	1	0-- room temperature not to be displayed 1-- room temperature to be displayed
15	selection of room temperature	0	0	1	0-- temperature sensor of return air 1--temperature sensor of wired controller

6.2 Parameter setting by YK – L

6.2.1 Enter the setting interface


- ① Make sure the remote controller is **off**
- ② Press the **two white button** at the down side simultaneously **more than 10s** to enter the address setting mode.
- ③ First, will display "**1**" , "**1**" ,
- ④ the above number means : Series parameter number, from **1~15**
- ⑤ the below number means : Meaning of parameter correspondence

For example:

Check "**6.1 Parameter Setting Items**" for number of parameters and corresponding meaning.


"1" , "1" , the indoor unit's address is **1#**

"4" , "32" , the indoor unit's type is **Wall - Mounted (L Type)**



6.2.2 Parameter Setting

1. Press the [^] or [v] button to change the parameter series number
2. Press the [IClean] or [ECO] button to change the parameter correspondence
3. Press the [MODE] button to send order (Sent signal to display panels or receivers), Then can hearing buzzer once



press "**MODE**" button to send order; When hearing buzzer once, it indicates successful setting


Press the "**up**" or "**down**" button to change the parameter series number

Press the "**Iclean**" or "**ECO**" button to change the parameter correspondence

6.3 Parameter setting by XK-02A

6.3.1 Enter the setting interface

- ① Press [**Filter Net Button**] for **5 seconds**, group number “**01**” of wired controller will be displayed in temperature zone of LCD screen and “**0101**” will be displayed in timing setting zone of LCD screen.
- ② “**0101**” means this indoor unit ID address is No. 1
- ③ Press [**+/- Button of Time**], “**0201**”, “**0301**”, “**0401**” “**0510**” will be displayed successively. Check “**6.1 Parameter Setting Items**” for number of parameters and corresponding meaning.



6.3.2 Parameter Setting


After press [**Filter Net Button**] for **5 seconds**, then

1. Press [**Time +/- button**] to change number of parameters (**1~15**), “**0101**” ~ “**1501**”
2. Press [**Mode Button**] once, “**0101**”, **01** will flash
3. Press [**Temp +/- button**] to change the value, for example “**0105**”
4. Press [**Mode Button**] to confirm

6.4 Parameter setting by XK-05A


6.4.1 Enter the setting interface

1. Press **“Function”** button for **10s** to enter the setting interface.
2. **“0303”** can check **“6.1 Parameter Setting Items”** for number of parameters and corresponding meaning.




6.4.2 Change series parameter number

Press **“up” / “down”** button to change the number (**1~15**), **“0101” ~ “1501”**



6.4.3 Parameter Correspondence Setting

1. Long press "**Function**" button for 5s, the second "0303" 03 will flash
2. Press "**up**" / "**down**" button to change the number
3. Press [**Function Button**] to confirm






Part4 Special Control

1. Special Control



1.1 Compressor emergency

1. This function is used for twin compressor models (**18-22HP**)

Dip Switch in Main PCB		Compressor Information						
		1# Comp. Abnormal 2# Comp. Normal						
2. When one of these compressors had a fault For example : 1 # compressor abnormal								
3. Set emergency function for 1# compressor, as right diagram (Change according “Part 3 - 4.1 Functions set by switch”) Then will shields all faults of 1# compressor.	1# Compressor emergency SW4 <table><tr><td>OFF</td><td>NO</td><td></td></tr><tr><td>1</td><td>2</td><td>3</td></tr></table> 		OFF	NO		1	2	3
OFF	NO							
1	2	3						
4. The system will only run 2# compressor								

1.2 Modular emergency (ODU)

1. This function should be used in $N \geq 2$ (N: A system's quantity of outdoor units)

Dip Switch in Main PCB 	
2. When one of these outdoor units had a fault, <i>For example : Slave 2 # abnormal</i>	
3. Set emergency function for Slave 2 #, as right diagram (<i>Change according “Part 3 - 4.1 Functions set by switch”</i>) Then will shields all faults of Slave2#	Modular emergency SW4 NO 3 
4. <i>Close the liquid and gas stop valve of slave 2#</i>	
5. Other outdoor units operate automatic, the outdoor unit (<i>Slave 2#</i>) which was choose emergency function will keep standby.	


1.3 Quiet mode

Quiet in cooling mode
Max frequency of compressor 90HZ
Max frequency of fan motor 49HZ(single fan modular)
Max frequency of fan motor 58HZ(twin fan modular)
Quiet in heating mode
Max frequency of compressor 100HZ
Max frequency of fan motor 49HZ(single fan modular)
Max frequency of fan motor 60HZ (twin fan modular)

1.4 Operation Priority

First-ON:
The first “ON” indoor unit determines the running mode of the whole system until shutdown.
Heating priority:
When any indoor unit receives the heating command, the outdoor unit runs according to the heating mode until the heating mode is stopped.
Cooling priority:
When any indoor unit receives the cooling command, the outdoor unit runs according to the cooling mode until the cooling mode is stopped.
VIP:
Manual address set the indoor unit's address to 63, 64, A system can have 2 VIP indoor units, VIP indoor unit determines the running mode of the whole system until.

1.5 ODU static pressure control

If the installation space the same as right diagram	Ⓒ < 1000 mm Ⓓ Air exhausting device 																																																
1. Air exhausting device is necessary to be added to improve the ventilation 2. Outdoor unit's static pressure should be set to 20 or 50 or 80Pa according the air exhausting device	Before power on, outdoor unit's static pressure can be set to 20/50/80Pa according to project demand (<i>Change according "Part 3 - 4.1 Functions set by switch" SW5</i>) ODU static pressure 20 Pa SW5 <table border="1"> <tr> <td>OFF</td><td>ON</td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>5</td><td>6</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>8</td> </tr> </table> ODU static pressure 50 Pa SW5 <table border="1"> <tr> <td>ON</td><td>OFF</td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>5</td><td>6</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>8</td> </tr> </table> ODU static pressure 80 Pa SW5 <table border="1"> <tr> <td>ON</td><td>ON</td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>5</td><td>6</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>8</td> </tr> </table>	OFF	ON							5	6	1	2	3	4	5	8	ON	OFF							5	6	1	2	3	4	5	8	ON	ON							5	6	1	2	3	4	5	8
OFF	ON																																																
5	6	1	2	3	4	5	8																																										
ON	OFF																																																
5	6	1	2	3	4	5	8																																										
ON	ON																																																
5	6	1	2	3	4	5	8																																										

1.6 Clean (Auto dust removal)

Outdoor fan motor run as opposite direction for a period of time to blow away the dust
(Choose the function according "Part 3 – 4.2.4 [C] Function Setting "- 【C.....2】)


1.7 Blow off Snow (Auto snow-blowing)

The fan motor will run for a period of time to blow away the snow (Choose the function according "Part 3 – 4.2.4 [C] Function Setting "- 【C.....4】)

※ System will respond this function only when the outdoor environment temperature [**Tao**]
≤ -5°C

1.8 Vacuum Pumping

For after-sale : If a system had a refrigerant leakage, should find out the leakage point and re-welding first, and there should be no any refrigerant in the system, so we can choose the **Vacuum pumping function** (*Choose the function according “Part 3 – 4.2.4 [C] Function Setting “ – [C....5]”*) to do Vacuum



1. Connect the vacuum pump and vacuum pressure gauge as above diagram
2. Through Master unit to set vacuum pumping function
3. Then outdoor units keep standby state and all EXVs keep ON state, the sub-cooling solenoid valve alternating switch for 5 minutes.

1.9 Economic locking (26℃)

Through Master unit to set the Economic locking function, (*Choose the function according “Part 3 – 4.2.4 [C] Function Setting “- 【C.....6】 ”*) All indoor units will run as energy saving mode state:

Cooling mode: indoor unit's set temperature **will be keep to 26℃** (lowest set temperature)

Heating mode: indoor unit's set temperature **will be keep to 20℃** (Highest set temperature)

1.10 Refrigerant Recycle

For after-sale: If one of the system's indoor unit must be replaced due to a refrigerant leakage point was find out in its evaporator

Then we can choose the **Refrigerant recycle function** through master unit (*Choose the function according “Part 3 – 4.2.4 [C] Function Setting “- 【C.....7】 ”*) to recycle refrigerant to outdoor units.

1. After choose this function		
2. Outdoor units will run cooling mode		
3. Close liquid stop valve		
4. When display error code F3: (high pressure protect) or F6: (low pressure protect) in digital tube, it means all refrigerant recycled to outdoor unit		
5. Close Gas stop valve		
6. long press exit button [Test] 5s to exit this function	Liquid stop valve	Gas stop valve

✗ If outdoor environment temperature $\leq 5^{\circ}\text{C}$, the system will not respond to outdoor unit's refrigerant recycle function.

1.11 Refrigerant Charging

For after-sale: If a system lack of refrigerant , then we can choose the **Refrigerant Charging function** through master unit (*Choose the function according “Part 3 – 4.2.4 [C] Function Setting “- 【C.....8】 ” to add refrigerant*

1. Choose the **Refrigerant Charging function** in Master unit's main PCB


2. Running cooling mode automatic, according running parameters, main PCB digital tube will display (*Refrigerant state*):

- **【F.....1】 : Refrigerant is not enough**
- **【F.....2】 : Refrigerant is enough**
- **【F.....3】 : Excess of refrigerant**

3. If **【F.....1】** was displayed in the tube, press **【Fun】** to add refrigerant, system will run as following:

- **Cooling mode**
- Outdoor units' **output capacity** $\geq 75\%$
- Sub-cooling valve (**EXV3**) **be closed**

4. prepare tools as below diagram in advance



5. Connect **1# connection hose** to **Service valve**

6. Open **1# valve** and **2# valve**

7. Then gas refrigerant will push out the air which inside of **1# connection hose** and **2 # connection hose**

8. Open **3# valve**

9. When **【F.....2】** be displayed, means additional refrigerant will be enough

10. Then **【F.....0】** will be displayed after 3 min, it means finish, system will stop running automatic , the **service valve** must be closed at the same time

Note:

※ System will respond refrigerant charging function only when meet the following 3 conditions at the same time :

1. Outdoor temperature “**Tao**” should $15^{\circ}\text{C} \leq \text{Tao} \leq 40^{\circ}\text{C}$,

2. Indoor temperature “**Tai**” should $10^{\circ}\text{C} \leq \text{Tai} \leq 32^{\circ}\text{C}$,

3. The quantity of indoor units which (**capacity** $\leq 1.5\text{HP}$) should less than 70% of total quantity of indoor units

Part5 Trouble shooting

1. IDU Fault code table..... Chyba! Záložka není definována.
2. ODU Fault code table Chyba! Záložka není definována.
3. Indoor unit error code display..... Chyba! Záložka není definována.
4. Outdoor unit error code display..... Chyba! Záložka není definována.
5. Outdoor unit trouble shooting..... Chyba! Záložka není definována.
6. Appendix..... Chyba! Záložka není definována.

1. IDU Error code table (No.16)

1.1 Temperature sensor failure (4)

Code	Definition	Possible reason for error code
A1	Indoor ambient temperature	1. Indoor unit's PCB failure 2. The fuse of indoor PCB is broken 3. Temperature sensor failure , or exceed test limit
A2	Evaporator mid temperature sensor	
A3	Evaporator inlet temperature sensor	
A4	Evaporator outlet temperature sensor	

1.2 Communication failure (2)

Code	Definition	Possible reason for error code
A9	The communication between indoor unit and outdoor unit failed	1. The communication wire between indoor unit and outdoor unit is broken. 2. Indoor unit power failure 3. Indoor PCB failure
AA	The communication between indoor unit and wire controller failed	1. The communication wire between indoor unit and outdoor unit is broken. 2. Indoor unit power failure 3. Indoor PCB failure 4. Wire controller is broken

1.3 Others failure (12)

Code	Definition	Possible reason for error code
A5	Indoor water pump failure	1. Water pump no power 2. Water pump switch short-circuit or unconnected 3. Water pump is broken 4. Drain pipe block or up lean 5. Indoor PCB is broken
A6	Failure of indoor PG fan	1. Fan motor failure 2. Fan motor block 3. The connection between PCB and fan motor failure 4. Indoor fan block
A7	Failure of reversible synchronous motor	1. Step motor failure 2. The connection between PCB and step motor failure.
A8	Indoor unit ERRPROM module failure	1. Indoor unit PCB is broken 2. Error module is broken
AC	More than 2 indoor units' central control system address repeated	The central control address setting incorrect
AE	Operation mode conflict	The operation mode setting incorrect
AH	Two or more indoor unit refrigerant system address repeated	System address setting incorrect
AJ	Indoor unit total capacity exceeded	Stop some indoor units
AF	The EXV leakage	1. EXV is blocked 2. Evaporator inlet sensor failure.
A0	The EXV open failure	3. Indoor unit's temp. sensor failure

2. ODU Error code table (No.65)

2.1 Communication failure (4)

Code	Definition	Possible reason for error code
J1	Communication failure between outdoor units	1. The communication wire between outdoor units is disconnect, short circuit or incorrect 2. Outdoor unit's main PCB failure 3. Outdoor unit's main power failed
J2	Communication failure between outdoor and indoor units	1. The communication wire between indoor unit and outdoor unit disconnect, short circuit or incorrect 2. Indoor unit's main power failed 3. Indoor unit's PCB failure 4. Outdoor unit's main PCB failure
J3	Communication failure between main PCB and compressor drive module	1. The connection between driving module and main PCB failure 2. The communication part of outdoor unit control PCB failure 3. Compressor driving module failure 4. Compressor failure 5. Main PCB failure
J4	Communication failure between main PCB and fan motor drive module	1. DC fan motor drive module failure 2. DC fan motor failure 3. Supply voltage exceed limit 4. Main PCB failure

2.2 Pressure sensor failure (2)

Code	Definition	Possible reason for error code
F1	【P _d 】 High pressure sensor failure	1. High pressure sensor failure 2. High pressure sensor connection is incorrect 3. Outdoor unit's main PCB failure
F4	【P _s 】 Low pressure sensor failure	1. Low pressure sensor failure 2. The connection between sensor and outdoor PCB incorrect 3. Outdoor unit's main PCB failure

2.3 Pressure abnormal (4)

Code	Definition	Possible reason for error code
F3	【P _d 】 High pressure too high	1. Exhaust pipe or condenser pipe block 2. Condenser dirty 3. Outdoor unit fan stop or low speed 4. Refrigerant overcharge
F6	【P _s 】 Low pressure too low	1. Indoor unit fan stop or low speed 2. Evaporator dirty 3. Indoor EXV full open in cooling mode (Outdoor EXV full open in heating mode) 4. Lack refrigerant 5. The pipe between evaporator and suction port block
F8	Compression ratio too high protection	Compressor failure
F9	Compression ratio too low protection	Compressor failure

2.4 Temperature sensor failure (10)

Code	Definition	Possible reason for error code
C1	【T _{ao} 】 ambient temp.	1.Temperature sensor failure 2.Test temperature exceed limit 3.Sensor connection is incorrect 4.Outdoor unit's main PCB failure
C2	【T _{def1} 】 Defrosting temp.	
C3	【T _{da} 】 discharge temp. of 1# comp.	
C4	【T _{db} 】 discharge temp. of 2# comp.	
C6	【T _s 】 Suction temp. of compressor	
C9	【T _{ho1} 】 Condenser outlet temp.	
CJ	【T _{d3} 】 Oil temperature	
CC	【T _{d4} 】 Liquid piping temp. of ODU	
CE	【T _{ho2} 】 Outlet temp. of PMV3	
CF	【T _{def2} 】 Outlet temp. of sub-cooler	

2.5 Temperature abnormal (3)

Code	Definition	Possible reason for error code
FH	Discharge temperature too low	Compressor failure
E3	【T _{da} 】 1# Compressor discharge temperature too high	1.System lack of refrigerant 2.DC inverter Compressor failure 3.Compressor air return filter block 4.EXV block 5.Gas stop valve was closed 6.Liquid stop valve was closed 7.dischagr sensor failure 8.Outdoor unit PCB failure
E4	【T _{db} 】 2# Compressor discharge temperature too high	

2.6 1# Comp. and drive failure (11)

Code	Definition	Possible reason for error code
31	Drive Module IPM protection (F0)	1. Low supply voltage, excessive current 2. Supply voltage exceed limit 3. Outdoor fan stop or low speed 4. Drive module temp. too high
32	Drive Module hardware protection	
33	Drive Module software protection	
34	Drive module unconnected	1.The connect of driving module and DC inverter compressor incorrect 2.Driving module failure 3.Compressor failure
35	Drive module current overload	1. Compressor overload 2. Compressor coil disconnect 3. Inverter driving board failure 4. Compressor failure
36	Drive module DC bus voltage over-voltage or under-voltage failure	1. Supply voltage below level 2. Supply voltage exceed limit 3. Drive module failure
37	Temperature sensor of drive module heat fins failure	Drive module failure
38	Drive module high temperature limit frequency failure	1. Driving module failure 2. Compressor failure 3. Outdoor unit fan stop or low speed
39	Drive module high temperature shutdown protection	1. Driving module failure 2. Compressor failure 3. Temperature sensor failure
3E	Drive module AC Input over current protection	Drive module failure
3F	Drive Module PFC protection (F0)	Drive module failure

2.7 2# Comp. and drive failure (11)

Code	Definition	Possible reason for error code
51	Drive Module IPM protection (F0)	1. Low supply voltage, excessive current 2. Supply voltage exceed limit 3. Outdoor fan stop or low speed 4. Drive module temp. too high
52	Drive Module hardware protection	
53	Drive Module software protection	
54	Drive module unconnected	1.The connect of driving module and DC inverter compressor incorrect 2.Driving module failure 3.Compressor failure
55	Drive module current overload	1. Compressor overload 2. Compressor coil disconnect 3. Inverter driving board failure 4. Compressor failure
56	Drive module DC bus voltage over-voltage or under-voltage failure	1. Supply voltage below level 2. Supply voltage exceed limit 3. Drive module failure
57	Temperature sensor of drive module heat fins failure	Drive module failure
58	Drive module high temperature limit frequency failure	1. Driving module failure 2. Compressor failure 3. Outdoor unit fan stop or low speed
59	Drive module high temperature shutdown protection	1. Driving module failure 2. Compressor failure 3. Temperature sensor failure
5E	Drive module AC Input over current protection	Drive module failure
5F	Drive Module PFC protection (F0)	Drive module failure

2.8 1# Fan motor and drive failure (5)

Code	Definition	Possible reason for error code
3A	Drive module high temperature	1. DC fan motor abnormal 2. DC fan drive module abnormal
3C	Drive module over current	
3H	Drive module start failure or running out of step	
3J	Drive module over-voltage or under-voltage	
41	Drive module IPM alarm	

2.9 2# Fan motor and drive failure (5)

Code	Definition	Possible reason for error code
5A	Drive module high temperature	1. DC fan motor abnormal 2. DC fan drive module abnormal
5C	Drive module over current	
5H	Drive module start failure or running out of step	
5J	Drive module over-voltage or under-voltage	
49	Drive module IPM alarm	


2.10 Others failure (10)

Code	Definition	Possible reason for error code
H1 (B1)	【HP1】 High pressure switch failure	1. High pressure exceed high pressure switch limit. 2. High pressure switch failure 3. High pressure sensor failure 4. Instantaneous power-off 5. Stop valve closed 6. Outdoor unit fan stop 7. Outdoor unit air outlet block 8. In heating mode indoor unit fan stop 9. In heating mode indoor unit EXV block
H5	Refrigerant shortage fault	System leakage
HF	Oil shortage fault	Once confirm the unrecoverable
HJ	Main power failure	1. Supply power phase-reversal 2. Supply power phase lack 3. Outdoor unit PCB failure
J5	Parameter set incorrect	1. Outdoor unit dial switch incorrect 2. Main PCB failure
J7	Outdoor unit main control PCB ERROM module failure	Main PCB failure
JJ	Indoor unit total capacity exceeding	Indoor units' total capacity over 130% of the outdoor units' total capacity
47	Indoor unit loss failure	1. Communication wire between indoor units failure 2. Indoor PCB failure 3. Power supply of indoor units failure
E1	The 4-way valve is fault	
E9	Drive refrigerant cooling pipe low temperature protection	

3. Indoor unit error code display

3.1 Error code display by YK-02A

After indoor and outdoor units shut down due to failure, failure code will display on wired controller. In case of normal protection, no failure code will display on wired controller. Among others, wired controller doesn't automatically send warning, which requires pressing CHECK button to display corresponding failure codes.

	Press”  ” to enter error code check “A1A2” means The last two failures are “A1””A2” through the “2.1 IDU Fault code table” to check error code definition, If there is no error, will display “- - - -”
--	--

3.2 Error code display by YK-05A

	Press “Function” & “Up” button at the same time to enter the error code check “E0A1”means the first error code “A1”, through the “2.1 IDU Fault code table” to check error code definition, “E2A3” means the second error code is “A3”
---	---

3.3 Error code display by display panel


“E0” error code




4. Outdoor unit error code display

For outdoor units, the error code displays on the main PCB (Master unit)


Outdoor unit control box



Outdoor unit main PCB





Digital tube in main PCB



Error code “**H5**” , through the “**2.2 ODU Fault code table**” to check the definition:
system leakage

Symbol Description





Definition of ports

Symbol Abbreviation	Detailed information
N R S T	Power input
TR_IN	Transform input
N02	AC contact
CH1	1# Compressor preheating
CH2	2# Compressor preheating
4WV1	4-way valve
SV1	Unloading valve
SV5	1# Vapor injection valve
SV6	2# Vapor injection valve
SV3	Sub-cooling valve
PWV1	1# Heating EXV
PWV2	2# Heating EXV
PWV3	Electronic expansion valve of Vapor injection
C_INV	Drive modular of compressor
C_FAN	Drive modular of fan motor
C_I/O	Communication Ports
HP1	High pressure switch
T _{ho2}	Outlet temperature of PMV3
T _{def2}	Outlet temperature of sub-cooler
T _{ao}	Environment temperature
T _s	Gas-liquid separator outlet/Suction temperature
T _{ho1}	Condenser outlet temperature
T _{def1}	Defrost temperature
T _{d1}	Discharge of compressor 1#
T _{d3}	Oil temperature
T _{d4}	Liquid piping temperature of ODU
T _{ho2}	Outlet temperature of PMV3
Pd	High pressure sensor
Ps	Low pressure sensor
TR_O	Transform output

XE

Ground wire

5. Outdoor unit trouble shooting

5.1 E3 E4 Error Code

E3 / E4 : Discharge temperature "*Tda*" "*Tdb*" too high

Compressor discharge temperature sensor detected $Td \geq 120^{\circ}\text{C}$ and Lasts for 10s, whole system will stop running, after 4 minutes later will restart, but if stop running more than 3 times within an hour, ODU PCB will display E3 or E4 error code. Stop running until power up again.



Check whether Lack of refrigerant

1. No additional refrigerant?
2. Low pressure is too low?
3. High temperature of IDU air outlet?

Yes



Add refrigerant

NO↓

Check whether Lack of frozen oil

Through monitoring software to check is the system frequent to run the oil return mode

Yes



Add oil

NO↓

Check whether high pressure too high

1. ODU fan running abnormal?
2. Condenser is dirty block?

Yes



1. Replace fan or fan motor
2. Clean the condenser

NO↓

Check whether refrigerant circuit is unblocked

1. IDU's coil of EXV is abnormal?
2. IDU's EXV is abnormal, through monitoring software to check the EXV's open degree
3. IDU's EXV is dirty block?

Yes



1. Replace power coil of EXV
2. Replace EXV



Contact the manufacturer's Technician

5.2 F8 Error code

F8 : Compression ratio too high protection

When detect the $pd / ps > 8$, then system begin to slow down the compressor running frequency . After the frequency was down to the lowest value and detected the $pd/ps > 8$ all the time *within 400s*. Then will appear F8 Error code, whole system stop running. ※ pd: High pressure value ps: Low pressure value



Stop valve is OFF?



Open

NO ↓

Condenser and evaporator dirty block?



Clean

NO ↓

Pipe is flattened?



Re welding

NO ↓

Heating EXV is abnormal? Through check the temperature is same or not which between inlet and outlet piping of the EXV.



Replace EXV

NO ↓

Pressure sensor is abnormal?



Replace sensor

NO ↓

System lack of refrigerants? Through check the discharge temperature 、 high pressure value and so on to judge.



Add refrigerant

NO ↓


Contact the manufacturer's Technician

5.3 F9 Error code

F9 : Compression ratio too low protection

When detect the $pd / ps < 1.8$, then system begin to increase the compressor running frequency . every 40s later detect again , After 45 cycles and the $pd / ps < 1.8$ remain the same . Then will appear F9 Error code, whole system stop running.

※ pd: High pressure value ps: Low pressure value



NO ↓

Contact the manufacturer's Technician

5.4 HF Error code

HF : *Oil shortage fault*

When detect the oil temperature is abnormal, low temperature near the environment temperature. In addition, discharge super-heat is normal. Then will appear HF Error code, whole system will stop running. Once confirm the unrecoverable



Oil temperature sensor is abnormal?



Replace sensor

NO ↓

Oil return capillary is blocked?



Replace capillary

NO ↓

Through monitoring software to check is the system frequent to run the oil return mode?




Add oil


NO ↓


Contact the manufacturer's Technician

5.5 HJ Error code





5.6 H5 Error code





5.7 FH Error code





6. Appendix

Relation between temperature sensor of compressor and resistance

R25=50KΩ±1%			
B25/50=3950K ±1%			
T [°C]	Rmin [KΩ]	Rnom [KΩ]	Rmax [KΩ]
-20	449.9	464.7	479.9
-19	425.7	439.5	453.6
-18	402.9	415.7	428.8
-17	381.5	393.4	405.6
-16	361.3	372.3	383.6
-15	342.2	352.5	363.0
-14	324.3	333.9	343.7
-13	307.5	316.4	325.5
-12	291.5	299.8	308.3
-11	276.6	284.3	292.2
-10	262.4	269.6	276.9
-9	249.0	255.7	262.5
-8	236.5	242.7	249.0
-7	224.5	230.3	236.2
-6	213.3	218.7	224.2
-5	202.7	207.7	212.8
-4	192.7	197.3	202.0
-3	183.2	187.5	191.9
-2	174.3	178.3	182.4
-1	165.8	169.5	173.3
0	157.7	161.2	164.7
1	150.2	153.4	156.7
2	142.9	145.9	148.9
3	136.1	138.9	141.7
4	129.7	132.3	134.93

5	123.6	126.0	128.4
6	117.8	120.0	122.3
7	112.2	114.3	116.4
8	107.1	109.0	111.0
9	102.1	103.9	105.7
10	97.42	99.08	100.8
11	92.97	94.51	96.06
12	88.74	90.17	91.61
13	84.73	86.05	87.38
14	80.92	82.14	83.37
15	77.29	78.42	79.56
16	73.84	74.89	75.95
17	70.57	71.54	72.51
18	67.46	68.35	69.25
19	64.49	65.32	66.15
20	61.68	62.44	63.20
21	59.00	59.70	60.40
22	56.44	57.09	57.74
23	54.02	54.61	55.20
24	51.70	52.25	52.80
25	49.50	50.00	50.50
26	47.37	47.87	48.37
27	45.34	45.84	46.34
28	43.41	43.91	44.41
29	41.59	42.08	42.57
30	39.84	40.33	40.82
31	38.18	38.66	39.15
32	36.59	37.07	37.55
33	35.07	35.55	36.03
34	33.64	34.11	34.58
35	32.27	32.73	33.20

36	30.95	31.41	31.87
37	29.70	30.15	30.61
38	28.50	28.95	29.40
39	27.37	27.81	28.25
40	26.29	26.72	27.16
41	25.24	25.67	26.10
42	24.25	24.67	25.09
43	23.31	23.72	24.14
44	22.41	22.81	23.22
45	21.53	21.93	22.33
46	20.71	21.10	21.50
47	19.92	20.30	20.69
48	19.16	19.54	19.92
49	18.44	18.81	19.18
50	17.75	18.11	18.48
51	17.08	17.44	17.80
52	16.44	16.79	17.14
53	15.84	16.18	16.53
54	15.26	15.59	15.93
55	14.69	15.02	15.35
56	14.16	14.48	14.81
57	13.65	13.96	14.28
58	13.15	13.46	13.77
59	12.69	12.99	13.30
60	12.23	12.53	12.83
61	11.80	12.09	12.39
62	11.39	11.67	11.96
63	10.98	11.26	11.54
64	10.60	10.87	11.15
65	10.23	10.50	10.77
66	9.880	10.14	10.41

67	9.537	9.792	10.05
68	9.211	9.460	9.715
69	8.897	9.141	9.391
70	8.595	8.834	9.078
71	8.306	8.539	8.778
72	8.028	8.256	8.490
73	7.759	7.983	8.212
74	7.501	7.720	7.944
75	7.254	7.468	7.687
76	7.016	7.225	7.440
77	6.786	6.991	7.201
78	6.565	6.765	6.971
79	6.352	6.548	6.749
80	6.147	6.339	6.536
81	5.950	6.138	6.331
82	5.761	5.944	6.133
83	5.578	5.757	5.942
84	5.401	5.577	5.758
85	5.231	5.403	5.580
86	5.069	5.237	5.410
87	4.912	5.076	5.245
88	4.760	4.921	5.087
89	4.615	4.772	4.934
90	4.474	4.628	4.787
91	4.338	4.489	4.645
92	4.207	4.354	4.506
93	4.081	4.225	4.374
94	3.958	4.099	4.245
95	3.840	3.978	4.121
96	3.726	3.861	4.001
97	3.616	3.748	3.885

98	3.509	3.639	3.773
99	3.407	3.534	3.665
100	3.308	3.432	3.560
101	3.212	3.333	3.459
102	3.119	3.238	3.361
103	3.030	3.146	3.267
104	2.942	3.056	3.174
105	2.858	2.970	3.086
106	2.778	2.887	3.000
107	2.699	2.806	2.917
108	2.623	2.728	2.837
109	2.549	2.652	2.758
110	2.479	2.579	2.683
111	2.410	2.508	2.610
112	2.343	2.439	2.539
113	2.279	2.373	2.471
114	2.216	2.308	2.404
115	2.156	2.246	2.340
116	2.097	2.186	2.278
117	2.040	2.127	2.217
118	1.985	2.070	2.158
119	1.932	2.015	2.102
120	1.880	1.962	2.047



Part6 Control System

1. **Controller Introduction** Chyba! Záložka není definována.
2. **Remote controller**..... Chyba! Záložka není definována.
3. **Wired Controller** Chyba! Záložka není definována.
4. **Centralized Controller** Chyba! Záložka není definována.
5. **Centralized Controller Software** Chyba! Záložka není definována.
6. **BMS-MODBUS Protocol**..... Chyba! Záložka není definována.
7. **BMS - BACNET Protocol**..... Chyba! Záložka není definována.
8. **Wireless Network Centralized Control System** ...Chyba! Záložka není definována.

1. Controller Introduction

Remote Controller		Wired Controller	
			
YK-L	YK-k	XK-02A	XK-05A

Centralized controller system		
		
CC-01	CC-02	Adapter

Centralized control software system				
				
RS-232 to RS485	RS-485/422 Repeater	Adapter	USB to RS485	software

BMS system	
	
MODBUS Gateway	BACNET Gateway


Wireless Network Control	
	
WIFI Modular	Software

1.1 Control Component List

Type	Model	Function Description
Remote controller	YK-K	1. General wireless remote controller 2. None address setting function
	YK-L	1. Background light. 2. Indoor unit's IP address setting function.
Wired controller	XK-02A	1. With a directly connecting 10m display board wire 2. Indoor unit's IP address setting function. 3. Control Max. 16 indoor units.
	XK-05A	1. Touch screw wired controller 2. Indoor unit's IP address setting function. 3. Control Max. 16 indoor units.
Centralized controller	CC-01	1. With weekly timer. 2. Control Max. 64 indoor units 3. Control Max. 4 systems
	CC-02	1. Touch screw 2. Control Max. 256 indoor units. 3. Control Max. 32systems
Centralized controller adaptor	DCZ-ZJB-SYE2	1. Centralized controller adaptor 2. Each system should be connected a adaptor
Centralized Control Software	/	1. Control Max. 4096 indoor units. 2. Control 32 systems.
Centralized Control Software Adaptor	USB to RS485	1. Accessories equipment of centralized controller software.
BMS system	MODBUS	1. Each system connect with a MODBUS gateway 2. Control Max. 32 systems
	BACNET	1. Each system connect with a MODBUS gateway 2. Control Max. 32 systems
Wireless Network Control	WIFI	1. Each system connect with a WIFI module 2. Control all indoor units in the system


2. Remote controller

2.1 YK-L



- | | |
|---|--------------------------|
| ① ON / OFF | ⑪ Sleep Function |
| ② Fan speed setting-High/Med/Low/Auto | ⑫ Timer on/off |
| ③ Temperature-Setting/Timer Range Setting | ⑬ I Feel Function |
| ④ Cooling Mode | ⑭ LED Display on/off |
| ⑤ Heating Mode | ⑮ Anti-function Function |
| ⑥ Vertical swing/Horizontal swing | ⑯ Clean Function |
| ⑦ Mode setting-Auto/cool/heat/dry/fan | ⑰ Electric Heating |
| ⑧ Turbo wind | ⑱ Spot swing |
| ⑨ Health Function | ⑲ Economic Function |
| ⑩ Silence Function | |

2.2 YK-K



- | | |
|---------------------------------------|---|
| ① Mode setting-Auto/cool/heat/dry/fan | ⑧ Temperature-setting/Timer Range setting |
| ② Fan speed setting-High/Med/Low/Auto | ⑨ ON/OFF |
| ③ Vertical swing/Timer Range Setting | ⑩ Timer on/off |
| ④ Feeling Function | ⑪ Horizontal swing |
| ⑤ Strong Wind | ⑫ Clean Function |
| ⑥ Sleep Function | ⑬ Health Function |
| ⑦ LED Display on/off | ⑭ Fungus-proof Function |

1 “ON/OFF” button

Press this button, the unit will start or stop, which can clear the timer or sleeping function of last time.

2 “SPEED” button

Press this button, speed will change as below:

Low → Mid → High → Auto



3 “▲ / ▼” button

- * When press ▲ button, the setting temperature will be increased by 0.5°C. When press ▼ button, the setting temperature will be decreased by 0.5°C.
- * The temperature will be changed quickly by pressing the button continuously and setting temperature range is 16°C to 32°C.

4 “COOL” button

- * Press the “COOL” button, you can directly enter cooling mode.

5 “HEAT” button

- * Press the “HEAT” button, you can directly enter heating mode.
- * Note: cooling only unit has no heating function.

6 “SWING” button (SWING ↔ and SWING ↑↓)

- * Up/down (left/right) setting is only valid in this mode; it will not affect louver position in other modes.
- * Up/down (left/right) swing has memory function, it can keep primary setting when turn off then turn on or switch from other modes to primary mode.

7. “HEALTH” button

- * Press this button; you can turn on or off the health function.

8. “SLEEP” button

- * Press SLEEP button, the sleeping indicator light of indoor unit flashes on.
- * The air-conditioner runs in sleeping mode for 10 hours and quit sleep mode, recover back to former mode.
- * The unit will turn off automatically if the timing mode is running out of time.

* Note: press the MODE or ON/OFF button, the remote controller clears sleeping mode away.

9. “iFEEL” button

* Press this button to set “iFEEL” function. The LCD shows the actual room temperature when the function set and it shows the setting temperature when the function cancelled.

* This function is invalid at Fan mode.

10. “DISPLAY” button

* In display mode, press button once, switch off “DISPLAY”, Press “DISPLAY” again, LCD will show ambient & setting temperature after flashing 5s. It's convenient for users to check ambient or setting temperature at any time in darkness.

11. “iCLEAN” button

* When remote controller is at the off state, press “iCLEAN” button, the unit runs “iCLEAN” function .

* The purpose of this function is to clean dust on evaporator and dry the inside water of evaporator and to prevent the evaporator going moldy due to water deposition and boasting strange smell.

* After setting “iCLEAN” function, press “iCLEAN” button or “ON/OFF “button to quit .

* The clean function will stop working after about 30 minutes running without any operation.

12. “ELE.H” button (for auxiliary electric heating IDU)

In heating mode, press this button, auxiliary electric heating will work.

13. “Anti-FUNGUS” button

* The purpose of this function is to dry the inside of the evaporator and to prevent the evaporator from going mouldy due to water deposition and thus dispersing strange smell.

* To operate the function: under “off” status of the A/C and the remote controller, press “Anti-UNGUS” button for one time, the buzzer keep beeping five times again after five times beep, indicating that this function is ready.

* To cancel the function: 1. under “OFF “status of the A/C and the remote controller, press “Anti-FUNGUS” button again.

14. “SPOT SWING” button

- * Press this button, the horizontal wind direction vanes can swing automatically, when you have the desired vertical wind direction.
- * Press “**SPOT SWING**” again, the horizontal wind direction vanes will be stopped depend on you.

15. “ECO” button

- * In cooling mode, press this button, the unit will run “**ECO**” economic operation mode which takes the least power consumption.
- * After running for 8h, it will automatically quit. You can press “**ECO**” button once again to quit .
- * Note: The unit will turn off automatically if the timing mode is running out of time.


16. Two white button: Addressing set

- * With the controller off, pressing the two white button simultaneously more than 10 seconds or more to enter address setting. This status displays only temperature and time parameters, temperature display area shows “Serial number” parameters, the range is 0-99. Time display area shows “Set value”, the range is 0-255. The initial value is 1.
- * By pressing “**▲ / ▼**” to set serial number + and -.Parameters within the serial number displays from 0 to 99 in circulation.

By pressing “**ECO**” and “**iCLEAN**” to set value number + and -.Parameters within the value number displays from 0 to 255 in circulation. After setting the two numbers, press the **MODE** button to confirm sending to ODU.

3. Wired Controller

3.1 XK-02A



ON/OFF button: Switch the unit **ON/OFF**.

Mode button: Auto-Cooling-Dehumidify-Heating 

Temp +/- button: Temperature adjustment range **16~32 °C**

Fan button : Auto-Low-Medium-High-Auto

Swing button: Press this button for the first time when operation, it will start the **swing** function. Push the button for the second time, cancel the swing function. (The function is available matched with the concerned unit)

Health button: Health mode

Sleep button: Sleep mode

Timer button: Press the button to **set Timer ON/OFF**, press the button then “**ON**” will flicker on the display screen. then press 【Clock +/- button】 and to adjust hour that uses 12-hour clock including “A.M.” and “P.M.” time; press the button again to complete the setting. The “**OFF**” setting is the same methods.

Remark: When setting functions such as mode, temperature, swing and fan speed, display screen displays all presetting parameters and remains constant; after reaching presetting time, air conditioner will automatically start as per presetting state.

After setting timing ON and OFF function, pressing button of 【Timer】 can cancel timing setting.

Notes:


1. Time sequence of timing ON and OFF determines the order of “**Timing ON-Timer OFF**” and “**Timer OFF- Timing ON**” . If the both are the same or either one is the same as time of current clock, it is invalid to press “**Timer**” button to confirm presetting time; after it reaches the presetting time, it will implement corresponding timing operation.
2. After setting time of timing ON and OFF, pressing “**Timer**” button can **cancel** timing.
3. Enter into time setting state of timing function; if there is no input related to time within consecutive 10 seconds, cancel the operation, return to previous state and go on with current time.
4. Default time of timer ON is 08:00 and default time of timer OFF is 18:00.

Clock +/- button: Normally display the clock set currently (display 12:00 for the first electrifying or resetting). When press the 【Timer button】 button for 5 seconds, the time display zone will flicker, then press 【Clock +/- button】 and to adjust hour that uses 12-hour clock including “A.M.” and “P.M.” time, press the 【Timer button】 again to complete the setting.

Filter Net button: When symbol of [Filter Net button] displays after wired controller receives “**Filter**” cleaning signal sent by indoor unit, press “**Filter Net**” button, “**Filter Net**” will go out and send filter cleaning reset signal to indoor unit; if [Filer] didn’t display, it will be ineffective in case of short pressing of filter button.

Self-check button: Press the button to **display** group number and **failure code** of this wired controller. (Failure code of wired controller for each unit displays for 3 seconds, then automatically exit after displaying failure state of the whole unit); **Continuously press the button** for 5 seconds, failure code will be cleared in the normal state.

3.2 XK-05A


Light sensation	
Infrared signal	
Timing button In the state of power-on, you can set shutdown countdown time. In the state of power-off, you can set starting-up countdown time.	
Fan speed button In the state of power-on, press "Fan" button to adjust fan speed	

Main functions

- 8-keytouch button input;
- Buzzer prompt tone function
- LCD+ white backlight;
- Receive the signal of wireless remote controller;
- Ambient temperature detection sensor;
- Display the failure of main controller;

Technical indicators

- Power voltage range: DC 12V;
- Working ambient temperature: **0 ℃~50 ℃** ;
- Working ambient humidity: RH20%~RH90%;
- Button: **Touch** button;
- Dimensions(W*H*D):120*120*20mm ;



Wire controller display

Swing button

In the state of power-on, you can setup and down swing or left and right swing function (different swing functions for different units)

On/Off control

Adjustment [^] [v] button

Increase or decrease the set temperature /humidity;

Long press both [^] [v] **button** to open the child lock.

Function buttons

Enter/Cancel function menu

Press [^] [v] **button** to select a desired function,


Press "**Function**" button to confirm.

Similarly, use the same steps to cancel the function operation


4. Centralized Controller

4.1 Button controller CC-01

(DCZCC-XK-SYE1)




4.1.1 Wiring Diagram



4.1.2 Centralized Controller Adaptor

Centralized controller adaptor is used with centralized controller together.



- ① To Centralized controller/ Supply power to controller (4 core wire)
- ② To next Gateway (2 core wire)
- ③ To VRF system communication terminal "A.B" (2 core wire)
- ④ Display slave address "01" means the first system."02" means the second system...
- ⑤ Setting **MODBUS-RTU** Slave Address (For button controller no need set)
- ⑥ **Dip-switch setting:**

ARV4,ARV5,ARV6, All DC type Min ARV	ON/ON/ON/OFF
Others	ON/ON/OFF/OFF

※ Indoor units' centralized ID address of all systems must be set to 1~63 (max 63)

※ Set according Part 3 Commissioning – 6. IDU parameter setting by controller,

For example: 2-1,2-2,2-3.....2-63, by YK-L remote controller

0201,0202,0203.....0263 ,by XK-02A or XK-05A wired controller

4.1.3 Centralized Controller function

- 1). Operation status of as many as **63 indoor units** can be **monitored**, including wind speed, set temperature, etc.
- 2). Mode, air speed and temperature setting are possible for individual/zoned/all indoor units.
- 3). **3** operation **modes** are available: Last-in Preferred, Centralized Control and Lock;
- 4). The **malfunctions** of the indoor units can be monitored and saved for inquiry;
- 5). Timed on/off is possible by specifying the exact time or by weekly schedule.
- 6). Any number of centralized units can be **zoned** with as many as 63 indoor units set as one zone, so that units in the same zone will carry out the same operation. (As the factory default, a centralized group is considered as a zone)

4.1.4 Operating Instructions

Enter main screen

During the initialization, no key inputs are processed until the end of the preliminary communication.

After the end of the initialization, the centralized controller will display main screen

2 0 1 1 / 0 1 / 1 8		1 0 : 0 0		T u e					
U n i t									
				W o r k i n g		0 5			
T o t a l		1 0		S t a n d b y		0 5			

Main screen a note :

Switching between the main screen a, b and c is possible by pressing the “**Style**” key. The main screen a,b,c are collectively called the “**the main screens**”.

Main screen a: displays the statistic data for the operation of the networked units.

Main screen b: displays list of the networked units.

Main screen c: displays the function information of individual units.

2011/01/18 10:00 Tue									
0102	0304	05	0708	1011					
25									

2011/01/18 10:00 Tue									
Zone 01		Mode: Cool							
Unit 01		Temp: 25℃							
		Fan: Low							

Main screen b

Note

1. When among all units, one or more are turned on, the operation indicator will light, otherwise, it will remain off.
2. Reverse displayed numbers indicate the units that are currently on and normally displayed ones indicate those that are off. Numbers that are not displayed indicate the units that are either not exist or communicatively failed. Press “**Page**” key to view the next page.
3. Displays the information of the individual unit whose **operation status** is indicated by the operation indicator. Press “**Page**” key to view the information of the next unit.

Quick on/off

1. When the operation indicator is on under main screen a, b, pressing “**Power**” key will turn off all units. When the operation indicator is off, pressing “**Power**” key will turn on all units.
2. Under main screen c, pressing “**Power**” key will only switch the operation status of the unit that is currently selected.


Set /change time

1. Under the main screens, press “**Set**” key to enter the page “**Set Manu**”:

1. Set Time
2. Timer Mode
3. Zone / Unit Set
4. Language Set

Page “Set Manu”

2. Select “**Set Time**” with the “**Select**” key , then press “**Ok**” to enter the page “**Time Setting**”.



Page "Time setting"

3. Under "**Time Setting**" screen, switch between the items using the "**Select**" key. The reversely displayed item is the selected one. Change it using the "**Change**" key.
4. Then, press "**Ok**" key to make the change effective and return to page "**Set Manu**".
5. If the "**Exit**" key is pressed during making the change, you will return to the main screen without the change being effective.
6. Pressing and holding the "**Change**" key for 2 seconds enables fast changing.

Timer Mode

1. Under the main screen, press "**Set**" key to enter the page "**Set Manu**". then, select "**Timer Mode**" using the "**Select**" key. The timer mode that is currently selected will display on the right of the line. using the "**Change**" key to select the desired timer mode. Then press "**Ok**" key to enter the corresponding page of timer mode.
2. Under the page "**Set Manu**", select "**Timer Mode**", then select "**No Timer**" using the "**Change**" key to **deactivate** the timer function.
3. The centralized controller support 3 timer modes: "**Current**", "**Daily**" and "**Weekly**". Only one timer mode can be activated at the same time.

Current/Daily Timing

Open	Time 1:	08:00
Close	Time 1:	17:00
Open	Time 2:	09:00
Close	Time 2:	16:00

Current/Daily Timing

1. Current and daily timer mode each has **4 timers** with 2 designated for open and the other 2 for close.
- 2. Switch** between the timers using the "**Select**" key. The reversely displayed item is the currently selected one.

3. Change the time of it using “**Change**” key. Pressing and holding the “**Change**” key for 2 seconds enables fast changing.
4. All timers work at **same** time.
5. Current timer works only for the current day, with the timer mode automatically **switched** to “**No Timer**”. The Daily timer always **works**.
6. If two timers are of the same time but different types, the one that is set to close will be **executed**.
7. If it is set to open and close the system at the **same** time, the close order will be executed.
8. The timers are executed by time order. If the current status of the current unit is the same as the target status set by the timer, the timer will be automatically **ignored**.
9. As **exemplified** in the above figure, the system is set to **open** at 8:00AM and **close** at 16:00 PM.

Weekly Timer

1. O p e n	0 8 : 0 0	S	M	T	W	T	F	S
2. C l o s e	1 7 : 0 0	S	M	T	W	T	F	S
3. N o t U s e d								
4. N o t U s e d								

The list of weekly timers

1. There are 8 weekly timers and the one with the frame shown is currently selected.
2. “**Open**” and “**Close**” **indicate** the related timer is an open and close timer, respectively. “**Not Used**” indicates that the timer is invalid. “**SMTWTFS**” indicate the day selection with each letter representing Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, respectively. The reversely displayed letter(s) indicates when the timer will work while the normally displayed one(s) indicates when it won’t work.
3. As exemplified timer 1 is currently selected, timer 1 and timer 2 are activated, other timers are invalid. Thus the timing is as follows: The system is set to open at 8:00 AM and close at 17:00 PM from Monday to Friday each week. No operation on Saturday and Sunday

4. Switch between timer 1-8 using “**select**” key, with the selected one shown with frame.
Now press “**Ok**” key to enter the change page of the corresponding timer and make desired settings.

M o d e :	O p e n
T i m e :	0 8 : 0 0
W e e k l y :	S M T W T F S

Change weekly timing

1. The 3 lines are “**Mode**”, “**Time**” and “**Weekly**” respectively.
2. The line with the frame shown is currently selected.
3. The “**Mode**” line is to set whether the timer is activated or not and whether it is set to open or close the unit.
4. The “**Time**” line is to set the **work time** of the timer.
5. The “**Weekly**” line is to set the days on which the timer is activated with those days indicated reversely.
6. **Switch** between the selected item using “**Select**” key , with the selected one shown with frame.
7. Press “**Change**” key to make desired changes.
8. After making all the changes, press “**Exit**” key to **return** to the previous screen. The setting is now finished.
9. The operation of the other weekly timers are the same as the above. After making the changes, press “**Exit**” key to return to the main screen.

Zone/Unit Set

1. Under the main screen, press “**Set**” key to enter the page “**Set Manu**”. Then, select “**Zone/Unit Set**” using the “**Select**” key. Press “**Ok**” key to enter the page “**Zone/Unit setting**”.

Z o n e / U n i t S e t u p
S e l e c t Z o n e : 0 1

Page “Zone/Unit setting”

2. Select the number of the zone to set using the “**Select**” key. Press the “**Ok**” key to distribute the members.


Unit	01	(Page 1 \ 2)
010203	040506070809101112	
131415161718192021222324		
2526272829303132		

Page “Member Distribution”

1. Under the page “**Member Distribution**”, select among the different unit numbers. The selected one will flash and the corresponding unit number will be displayed in the first line. using the “**Change**” key to decide whether to join the current zone. The reversely displayed numbers belong to the current zone while the normally displayed ones do not belong to the current zone.
2. Press “**Page**” keys to display other pages.
3. After all members are set, press “**Ok**” key to finish the setting of the current zone.
4. To set other zones, select the corresponding numbers and repeat the above operation.

Language Set


1. Under the main screen, press “**Set**” key to enter the page “**Set Manu**”. Then, select “**Language Set**” using the “**Select**” key. Press “**Ok**” key to enter the page “**Language Setting**”.

Page “**Language Setting**”

2. Under page “**Language Setting**”, press “**Change**” key to select the desired language : Chinese or English.
3. After selecting the desired language, press “**Ok**” key to activate that language.


Zoned Control

1. Under the main screens, press “**Control**” key to enter the page “**Set Manu**”:



Set Manu a

1. Under the page “Set Manu a”, press “Change” key to select among the 3 control modes: “All”, “Zone” and “Unit”. After selecting the desired mode, press “Ok” key to enter the submenu.
2. Pressing “All” mode will directly open the page “Control Setting” and others will open the page “Set Manu b”. Select the target code and press “Ok” to enter the page “Control Setting”.



3. In the page “Control Setting”, the items displayed on the left are the control targets and those displayed on the right are the specific controls. Press “Select” key to switch between the different items and change the controls using “Change” key. After changing the setting, press “Ok” key to make the change effective.

Centralized Control and Lock Functions

1. Under the main screen, press “Centralize” key to switch between the regular, centralized and lock modes.
2. The upper right icon on the main screen indicates centralize status.
3. The icon is not displayed in the regular mode and the indoor unit is controlled in “Last-in Preferred” mode.

4. In the centralized mode, a  icon will display with the indoor unit run under the settings of the centralized controller, but the remote control and line control work for the open and close of the indoor unit.
5. In the lock mode, a  icon will display with the operation status of the centralized controller remain unchanged. The remote control and the line control do not work for the open and close of the indoor unit.

Failure Inquiry Function

1. Under the main screens, press and hold the “Style” key to enter the “Historical Failures Inquiry” screen.

F a u l t		(0 1 / 2 0)
U n i t	0 1	
R e c e n t l y	:	a 3
P r e v i o u s l y	:	j 4

Historical Failure Inquiries

2. Under the page “Historical Failure Inquiry”, press “Select” key to switch between the historical failures of each unit, with units that have no historical failures



For the meaning of the specific trouble code, refer to the technical manual of the unit.

4.2 Touch controller CC-02




Dimension : Front 177*116*12.5mm ; behind : 120*60*26mm

4.2.1 Interface specification




- ① Indicator light
- ② RJ45 WAN
- ③ RS485 interface 1: B1- signal line negative pole; A1- signal line positive pole; G- signal ground wire
- ④ RS485 interface 2: B2- signal line positive pole; A2- signal line positive pole; G- signal ground wire
- ⑤ 2 Way DI fire input interface: IN-1- input port; IN-2- input port; G- signal ground wire
- ⑥ AC~220V power input: L- FireWire; N- zero line; P- protection ground wire

4.2.2 Wiring Diagram



4.2.3 Centralized Controller Adaptor

Centralized controller adaptor is used with centralized controller together.



1. To VRF system communication terminal “A.B” (2 core wire)
2. To next Gateway and or To Centralized controller (2 core wire)
3. Display slave address “01” means the first system. “02” means the second system...
4. Setting **MODBUS-RTU** Slave Address
 - 4.1 Press “+” or “-” to activate the slave address setting functions;
 - 4.2 Press “+” and “-” at the same time for 5 seconds , then the Digital Display will be Flashing every second;
 - 4.3 Press “+” to add the Slave Address , Press “-” to decrease the Slave address;
 - 4.4 After Setting Address finish , wait 5 seconds , then the Digital Display will stop Flashing and display the Slave Address.
5. POWER L/N 220V~

6. Dip-switch setting:


ARV4,ARV5,ARV6, All DC type Min ARV	OFF/OFF/ON/OFF
Others	OFF/OFF/OFF/OFF

※ Indoor units' centralized ID address of all systems no need to set


4.2.4 Centralized Controller function

AUX touch screen centralized controller is a multifunctional device that can control up to **256 indoor units / 32 systems** within a maximum connection length of **1200meters**. Users could enjoy the flexibility of either controlling multiple units as a **group** or controlling **each** unit individually.


4.2.4.1 Auto scanning indoor units





4.2.4.2 Indoor units operation



4.2.4.3 Grouping / region setting



4.2.3.4 Weekly Schedule Control




4.2.3.5 Multiple Lock function




5. Centralized Controller Software

5.1 System overview



5.2 Centralized Controller Adaptor

Centralized controller adaptor is used with centralized controller together.



- ① To VRF system communication terminal "A.B" (2 core wire)
- ② To next Gateway and or To Centralized controller (2 core wire)
- ③ Display slave address "01" means the first system. "02" means the second system...
- ④ Setting MODBUS-RTU Slave Address
 1. Press "+" or "-" to activate the slave address setting functions;
 2. Press "+" and "-" at the same time for 5 seconds , then the Digital Display will be Flashing every second;
 3. Press "+" to add the Slave Address , Press "-" to decrease the Slave address;
 4. After Setting Address finish , wait 5 seconds , then the Digital Display will stop Flashing and display the Slave Address.
- ⑤ POWER L/N 220V~

⑥ Dip-switch setting:

ARV4,ARV5,ARV6, All DC type Min ARV	OFF/OFF/ON/OFF
Others	OFF/OFF/OFF/OFF

5.3 Features

Users do not need to arrive the harsh environment of the site, they can **monitor** the function of units **just through computer**. These greatly improve convenience of **daily management** and the efficiency of **central** air conditioners;

Centralized control can **improve** the **efficiency** of air conditioners. It is more **energy-efficient** and environmental

Timely find the fault and save the maintenance cost of air conditioner units, **minimize losses**

Timer function with multi-period week, fully **automated schedule** planning of unit;

This system is suitable for **all DC inverter ARV** types of AUX;

Each **ARV** unit can **access** at most **63** indoor sets;

This **system** can access at most **64** ARV outdoor systems, it need to access **repeater** to increase **RS485** network equipment if the outdoor systems are **more** than 64. The way of wiring is instructed in Engineering installation and wiring description;

Every ARV unit need to **configured** a **communication adapter** plate;

If PC has **RS-485 interface**, there is no need to configuration **RS-232 to RS-485/422** Optically isolator.

5.4 Main components of Centralized Controller System

NO.	Main Components	Requirement & Function
1	Host computer 	Operation system: Windows XP SP32 and above, Windows 7
2	Adapter plate 	Computer and communication protocol and unit end communication protocol are incompatible with each other, must add communication adapter plate to <i>make both communicate</i> . Each ARV system matches 1 adapter plate.
3	RS-232 to RS-485/422 	The centralized control system RS485 network signal conversion for RS232 serial signal to achieve the <i>interconnection of computers</i> with centralized control system.

4	USB to RS-485/422 	The centralized control system RS485 network signal conversion for USB to achieve the interconnection of laptops with centralized control system.
5	RS-485/422 Repeater 	<i>Extend the communication distance and increase the number of RS-485 bus network.</i> The repeater is not required, only when there is more than 30 systems or communication distance is more than 800 meters.


5.5 Software install and uninstall

1. Run setup exe in CD to **install**;

2. If operation system has not installed Windows Install 3.1 and Windows .NET Framework 3.5, the installation program will install the two program first; when programs installation is completed, system installation will be continue, the default installation path is D:\Program Files\Aux Group\AUX_ARV_Setup

3. uninstall: select [Control Panel- Add or Remove Programs - AUX_ARV_Setup], click "Cancel" to uninstall.

5.6 Software introduction Main interface



Area 1--Serial **setting** area, choose the serial and press “Start Working” button, system will in operation, press “Stop Working” button, system will stop working;

Area 2--The **inquire** area for air conditioner unit, it can be divided into the system inquire and user-defined group inquire, the inquired unit will be displayed in area 4.


Area 3--Display area of single air conditioner **indoor unit**, select one of indoor units in area 4, then the area will display the name, ID (address of indoor unit) , system belonged ,group belonged, current condition, the room temperature of indoor unit , failure etc.

Area 4--Display area of air conditioner **group**, as shown in above picture, it displayed all the indoor unit in the group System01.

Area 5--**Control** area of air conditioner, it can control one single air conditioner and some air conditioner group, this will be described in detail later.

5.6 System initial setting

Click “**Air condition Config**” in area 4, it will enter the interface of system initial setting. Initial setting is divided into 3 parts: added/removed outdoor unit system, added/modified/removed air conditioner, add/changed user-defined group.



Added/removed outdoor unit system

Area 6 shown in the **figure** above is the operation area of added/removed outdoor unit system. The **quantity** of outdoor unit system of the whole project must match with the added one in figure 6, and the centralized control **address** (the address displayed on communication adapter plate)of every system must correspond with the system serial number.

Note:

If the outdoor unit system deleted, the indoor unit belonged in it will also be delete! Please handle with care.


Added/deleted indoor unit

Area 7 shown in the figure above is the operation area of added/deleted indoor unit. Before added, user need to select one option in area 6 shows that he would add indoor unit


in that outdoor system(the added quantity of indoor unit system must match with the actual quantity in the outdoor system).

5.7 Concrete operation

Click “**Add air condition**” button, the following dialog box will pop up




Click Based On Gateway button, there will **generate** a **name** (the red circle part in the figure below) according to indoor unit address and the system it belongs; click Custom button, user need to set a name by himself.



Then is to **choose** the **group** the air conditioners belong. User can choose a group defined by himself in Area Select. If there has not user-defined group, user can establish a user-defined group in Create nodule, detail explanation in Added/changed user-defined group. Click "OK" to complete new group addition after the completion of the new group added.

5.8 Added/changed user-defined group



The red circle part in the figure above is the added and changed operation area.


If user need to **add new group**, first, click New Zone button and input the name of user-defined group, then click Add Zone button, here will show the name inputted just now , establishment complete;

If user need to **modify the name of group**, select the group in Zone Select , input the new name, then click the Rename button, modification complete when the new name show in Zone Select

Note: Group deletion does not support now, be **careful** when **adding**.

5.9 System query operation


System query operation includes system query and user-defined group query. Query ways can be chosen as the figure below:




◇ If the chosen group is in According to System, then all the unit condition of the group will be displayed in area 4(area 4 will display the condition of all the indoor unit in System01 as the above picture shows).

◇ If user chooses one of the group in According to Zone, area 4 will display the condition of

all the units in it. In addition, user can move the indoor unit to other groups arbitrarily under the state of user-defined group query, its operation as follow figure:



When system is working(click Start Working in area 1), area 4 will display all the working condition if Indoor unit, as shown in the following figure



- ◇ No background is turned off;
- ◇ Green background is turned on;
- ◇ Red background is system failure;
- ◇ Yellow background is communication failure or electrical failure.

5.10 System control operation

System control can be divided into single unit control; group control and weekly group timing control 3 parts. Single unit control achieves the controlling of one indoor unit; group control achieves the controlling of System group and Zone group; weekly group timing control achieves the weekly timing control of Zone group (user-defined group).

1) Single unit control

Aircondition Control System01--Control

ON/OFF OFF Lock Work Mode Auto Lock

Temp Set 24°C Lock Indoor Fan Set Auto Lock

Apply

Besides on/off, **temperature** setting, **mode** setting, **indoor speed** setting, single unit control **added** the **lock** function (lock the 4 function above). If one function is locked, user cannot use it. For example, if ON/OFF is lock(choose Lock in ON/OFF), user cannot turn on/off the locked unit by remote or wired controller.

Indoor unit will executive command when click Apply after setting completed.

2) Group control

Group control achieves the unified control of one group, setting interface is shown as following figure:

Aircondition Control System01--Control

ON/OFF OFF Lock Active Work Mode Auto Lock Active Week Plan

Temp Set 24°C Lock Active Indoor Fan Set Auto Lock Active

Apply

Besides the **general control** and **locking control** of single unit control, group control is added the Active function. The matching state of indoor unit will change only when choose Apply function, unselected ones stay unchanged. For example, choose ON and Active, all the indoor units will be turned on, but the temperature, mode, speed will not be changed like the setting of group.

Indoor unit will executive command when click Apply after setting completed.

3) Weekly group timing control

Weekly group time control is one of the control function in **user-defined Zone**, system group has no this function, setting can be chosen only when the user-defined **region** is **selected** in **query**. Shown as figure below:

Then setting dialog box will pop out when Week Plan is selected, shown as figure below, after **completion** of set, click the "OK" button to finish the setting.

Notes:

1. All the related intellectual property rights as System patent right, software copyright etc. ownership belongs to Ningbo AUX Electrical Company Ltd. Any unit or individual shall not copy, assignment, transact or use related production in other ways without permission. Otherwise Ningbo AUX Electrical Company Ltd. will have the right to pursue legal responsibilities.
2. If system is damaged by suffering a natural force majeure (such as earthquake fire typhoon, etc.), all losses should be responsible for system investors.
3. The user should use legal copy of Windows XP or Windows 7 and other legal copy of related software and antivirus software, make sure the computer is virus free and the Computer Independent Connecting Billing System is unaffected by other network or external port (**USB port etc.**), otherwise it is the users' responsibilities if there is any lost or

damage.

3. The user should use authorized **computers** along with **UPS**, the UPS should use the standard that it can keep the computer working for at least one hour if the power is suddenly cut off, and during this one hour the administrator would take care of the computer. It is users' responsibilities if any accident or **data loss** happened because of a **sudden power failure**.

4. The user must make sure that the Photoelectric isolating **converter** is placed in a **safe place** that the converter is not easily damaged by people, make sure the wiring terminal is not loose leading to poor contact, and make sure the power is NOT easily cut off, otherwise it is the users' responsibilities if there is any lost or damage.

5. To make sure the system work for a long time, the user should **regularly check** and **repair** it, **reboot** the **computer** at a fixed time **every day**, so that the computer could run in a good environment, ensure the reliability of the system, release the computer resource. Here is what users should do, **first stop** the communications of **Billing** System, then **exit** it, **reboot** the computer, open the software after the computer is **rebooted**.

6. BMS-MODBUS Protocol

6.1 MODBUS-RTU Parameter

6.1.1 Configuration: Provided to the BMS management

MODBUS STYTLE	MODBUS-RTU	AUX ARV MODBUS-RTU ProtocolV1.3  AUX ARV MODBUS-RTU Protoc
Baudrate	9600	
Data-Bit	8	
Stop-Bit	1	
Check	even	
Slave-ID range	1~64	
MODBUS CODE	01,02,03,04,05,06	
SUPPORT Broadcast	NO	

6.1.2 Input Register: There are 14 parameters of each indoor unit can be monitored

Input Register Address	Content	Types	Notes
0	1# Indoor State	signed word	0-OFF / 1-ON / 2-Not Exist or Not Found
1	1# Indoor Type	signed word	Indoor Type (0,1,4,5,8,9,10,14,11,15,18,19-Cassette) (2,6,20,21-ESP Duct) (3,7,13,17-Ceiling & Floor) (12,16-Wall-Mounted) (22-Fresh Air Unit)
2	1# Indoor HP	signed word	Indoor Unit HP
3	1# Indoor Energy	signed word	Indoor Unit Energy
4	1# Indoor Mode	signed word	Control Mode(0-Auto/ 1-Cool/ 2-Dehumi/ 3-Healthy dehumi / 4-Heat / 5-Dry / 6-Flow)
5	1# Temperature Set	signed word	16~32℃
6	1# Indoor Fan Speed	signed word	Fan Speed(0-Stop/ 1-High/ 2-Medium/ 3-Low)
7	1# Indoor Error Code	signed word	Error Code

8	1# Indoor Tai	signed word	Display return air temperature
9	1# Indoor Tei	signed word	Display evaporator inlet temperature
10	1# Indoor Tem	signed word	Display evaporator central temperature
11	1# Indoor Teo	signed word	Display evaporator outlet temperature
12	1# Indoor Filter	signed word	0: Disable, 1: Enable
13	1# Reserved	signed word	/

6.1.3 Coil: There are 10 parameters of each indoor unit can be write / set (value is 0/1)


Coil Address	Content	Value/W	Data Type
0	1# Indoor ON/OFF	0	BOOL
1	1# Indoor ON/OFF Lock	0	BOOL
2	1# Indoor Control Mode Lock	0	BOOL
3	1# Indoor Temperature Set Lock	0	BOOL
4	1# Indoor Fan Speed Lock	0	BOOL
5	1# Indoor Up/Down Fixation	0	BOOL
6	1# Indoor Left/Right Fixation	0	BOOL
7	1# Indoor Sleep	0	BOOL
8	1# Indoor Healthy	0	BOOL
9	1# Indoor Filter	0	BOOL

6.1.4 Holding registers: There are 4 parameters of each indoor unit can be write / set


Holding Register's address	Content	MIN_ Value	Default Value	MAX_ Value	Data Type	Unit	Remark
0	1# Indoor Control Mode	0	0	6	SIGNED WORD	/	0-Auto/ 1-Cool/ 2-Dry /4-Heat / 6-Fan
1	1# Indoor Temperature Set	16	24	32	SIGNED WORD	°C	16~32
2	1# Indoor Fan Speed	0	0	6	SIGNED WORD	/	1-High/ 2-Medium/ 3-Low/ 5-Auto
3	1# Indoor Reserved	0	0	6	SIGNED WORD	/	/

6.2 Overall structure

Each MODBUS Gateway support 1 ARV system



6.3 Hardware Features




- ① To VRF system communication terminal “A.B” (2 core wire)
- ② To next Gateway & to Network work-station (2 core wire)
- ③ Display slave address/ “01” means the first system.”02” means the second system...
- ④ Setting MODBUS-RTU Slave Address/
 - 1. Press “+” or “-” to activate the slave address setting functions;
 - 2. Press “+” and “-” at the same time for 5 seconds , then the Digital Display will be Flashing every second;
 - 3. Press “+” to add the Slave Address , Press “-” to decrease the Slave address;
 - 4. After Setting Address finish , wait 5 seconds , then the Digital Display will stop Flashing and display the Slave Address.
- ⑤ Power supply 220V
- ⑥ Dip-switch setting: OFF/OFF/ON/OFF

6.4 Project Commissioning

6.4.1 Make sure ARV system was **commissioning** successful

6.4.2 Make sure **MODBUS Gateway** was **connected** correct




Note:

1. Each Gateway should be set **address**, For example : 4 systems , address from 01 ~ 04

2. Each Gateway (16422001000001) should be **Refresh program**(Factory setting)

6.4.3 **Check** if Gateway is working normal or not, test by a software (MODBUS Poll)



6.4.4 Last, we can deliver the project to the BMS administrator, they will according "**AUX ARV MODBUS-RTU ProtocolV1.3**"table to do management

7. BMS - BACNET Protocol

7.1 BACNET Parameter Variable

There are 9 parameters of each indoor unit can be monitored or set.

Idx	Function	Note
1	ON/OFF	Indoor Units' ON/OFF state command and feedback.
2	Mode	Indoor Units' Mode (AUTO/COOL/DEHUMI/FAN/HEAT) command and feedback.
3	Temperature. Set	Indoor Units' ambient temperature command(range : 16°C ~32°C) and feedback.
4	Fan Set	Indoor Units' fan command (High/Medium/Low/Auto) and feedback.
5	Ambient Temperature	Indoor Units' ambient temperature.
6	Error	Indoor and outdoor Units' error.
7	ON/OFF Lock	A type of command used for forbidden users operating ON/OFF command by remote controller and wire controller.
8	Mode Lock	A type of command used for forbidden users operating Mode command by remote controller and wire controller.
9	Temperature. Lock	A type of command used for forbidden users operating Tempr. Set by remote controller and wire controller.

Note :

The **ON/OFF Lock, Mode Lock, Temperature Lock** is inactive after indoor units' Power-Off.

Index	Function	Object Name	Object Type	Unit	Note
1	ON/OFF	Indoor(YY_XX) On/Off	BV		1: ON 0: OFF
2	Mode	Indoor(YY_XX) Mode Setting	AV		0: Auto Mode 1: Cool Mode 2: Dehumi Mode 3: / 4: Heat Mode 5: / 6: Fan Mode
3	Temp. Set	Indoor(YY_XX) Temp. Set	AV	°C	Range: 16~32
4	Fan Set	Indoor(YY_XX) Fan Set	AV		1 : High Fan 2 : Medium Fan

					3 : Low Fan 4 : / 5 : Auto Fan
5	Ambient Temp	Indoor(YY_XX) Tai	AV	°C	
6	Error	Indoor(YY_XX) Error	AV		Error Code
7	ON/OFF Lock	Indoor(YY_XX) On/Off Lock	BV		1: Lock 0: Unlock
8	Mode Lock	Indoor(YY_XX) Mode Lock	BV		1: Lock 0: Unlock
9	Temp. Lock	Indoor(YY_XX) Temp Lock	BV		1: Lock 0: Unlock


Note :

YY : ARV System Address(Range : 01~04); **XX**: ARV indoor units Address(Range : 01~64);


7.2 Overall structure

Each BACNET/IP Gateway has 4 RS-485 ports which can support 4 ARV systems

The COM Ports of ARV BACNET Gateway is connect with the ARV ODU/IDU Network



Any client device that support the BACNET/IP Protocol can integrate to BMS system by HUB



7.3 Hardware Features



Power

DC24 , 7W

Convenient Wiring

LAN(Reserve)、WAN、4 RS485 Ports

Dimension

115×35×135 mm

Installation Type

Slide-way Type

7.4 Web Configure


7.4.1 The BACNET Gateway IP and Computer IP should in the same network Segment

1. Power on, connect the RJ45 Port at the computer with the 'WAN' Port at BACNET Gateway.
2. Set the computer IP at Internet Protocol (TCP/IPv4):
 IP Address: 192.168.100.x (x range: 2~252);
 Subnet Mask: 255.255.255.0;
 Default Gateway: 192.168.100.1;
 Click 'OK'.
3. Open the Google Chrome or Firefox explorer, input '**192.168.100.126**', then the '**login**' Page will be shown. Input name: admin, password: admin, click 'Login', then go into the Configure Page.



7.4.2 Configure the Driver Management

1. Go into the '**Driver Management**' Page. Click '**Advanced**'—'Driver Management':



2. Add ARV Driver

The screenshot shows the 'Driver management' section of the interface. On the left, there is a sidebar with options: Gateway status, Driver management (selected), Cloud config, and Network config. The main area has tabs for 'Basic' and 'Advanced'. Under 'Basic', there is a '+ Add driver' button and a table with columns: Driver type, Device name, Driver name, and Operation.

Step 1: Click Add Driver. A red arrow points from the '+ Add driver' button to a text box labeled '1. Click Add Driver'.

Step 2: Input Driver name. A red arrow points from the 'Driver name' input field in the 'Add driver' dialog to a text box labeled '2. Input Driver name'.

Step 3: Click Add. A red arrow points from the 'Add' button in the 'Add driver' dialog to a text box labeled '3. Click Add'.

3. When finish these steps, the content is shown as follows.


The screenshot shows the 'Driver management' section after adding a driver. A text box at the top says: 'If you want to remove the driver information, then click .'. Below it is a table with columns: Driver type, Device name, Driver name, and Operation. The table contains one row: VRF, ARV, AUX. The 'Operation' column has a delete icon (X) and an edit icon (pencil). A red arrow points from the text box to the delete icon.

Total: 1


Before removing the driver information, you should make sure all of the indoor/outdoor information has been removed.

8.4.3 Add ARV System Information

1. Click 'Basic', then click the  at channel list to add the ARV system.




2. A dialogue will be shown




7.4.4 Add indoor units' information

We should select the ARV system before Add the indoor unit,

1. Select the ARV System.



2. Add indoor units as follows.




3. After finished, it is shown as follows.




7.4.5 Download the Indoor units' information

After finish adding the indoor units' information, we should **download** the information to **activate** the BACNET side.


1. Click the indoor unit's icon, then shown the dialogue as follows;



2. Click the 'Config' button, the BACNET information will be shown as follows,



3. Click 'Deploy' button, then shown the dialogue as follows. Click 'Update'.



4. After Update, click the '**Test**' Button to make sure all the indoor units' BACNET information is right

名称	别名	设备ID	数据项ID	值	状态
Indoor0h1	Indoor_01_01_FanSet	0	undefined	1	good
Indoor0h4	Indoor_01_01_ModeSel	0	undefined	1	good
Indoor0h7	Indoor_01_01_OnOff	0	undefined	0	good
Indoor1	Indoor_01_01_TempRSe	0	undefined	16	good
Indoor6h1	Indoor_01_01_OnOffLo	0	undefined	0	good
Indoor6h2	Indoor_01_01_ModeLoc	0	undefined	0	good
Indoor6h3	Indoor_01_01_TempRLc	0	undefined	0	good
Indoor10	Indoor_01_01_Tai	0	undefined	21.4	good
Indoor8h	Indoor_01_01_Error	0	undefined	0	good

Note, if the indoor unit's state is Bad, it will be shown as follow.


Test					
This section displays the acquisition data of the device, which is used to verify that the configured data item is correct.					
Name	Alias	Device ID	Data item ID	Value	State
Indoor0h1	Indoor_01_01_FanSet	0	undefined	-1	bad
Indoor0h4	Indoor_01_01_ModeSel	0	undefined	-1	bad
Indoor0h7	Indoor_01_01_OnOff	0	undefined	0	bad
Indoor1	Indoor_01_01_TempRSe	0	undefined	-1	bad
Indoor6h1	Indoor_01_01_OnOffLo	0	undefined	0	bad
Indoor6h2	Indoor_01_01_ModeLoc	0	undefined	0	bad
Indoor6h3	Indoor_01_01_TempRLc	0	undefined	0	bad
Indoor10	Indoor_01_01_Tai	0	undefined	-1	bad
Indoor8h	Indoor_01_01_Error	0	undefined	-1	bad

For the bad state, we can solve it by follow steps:

- **Check** if the indoor unit set in the **BACNET** Gateway is **exist**. In other words, the indoor unit's address must **match** with the exist one, Or the indoor unit setting in the BACNET Gateway doesn't make sense.
- **Communication** error between the Indoor unit and Outdoor unit side at RS-485 port.

7.4.6 Download the BACNET Gateway Configure

1. Click 'Advanced'–'**BACnetConfig**' , select '**IP**', click '**Deploy**'.



2. After Finished, all configuration success.

7.4.7 Set BACnet Gateway WANIP Address

The last work is set BACnet WAN IP address, so it can be accessed by other BACnet devices.

Suppose the Network Segment is 192.168.1.x, and the BACnet gateway WANIP Address is Set as 192.168.1.4, the default gateway is 192.168.1.1. It will be set as follows:

a. Click 'Advanced'

Basic Advanced

Gateway Status

1. Click Advanced

Hardware	AnyLink 100
Serial number	1400162
Firmware	BG-V1.3.34
Agent version	V3.1.0

b. Click 'Network Config'

Basic Advanced

Network config

2. Click Network

Hostname: id0162

WAN: ☒ Static IP ☐ Dynamic IP

IP address: 192.168.100.126

Subnet mask: 255.255.255.0

Default gateway: 192.168.100.1

DNS server: 114.114.114.114

LAN: ☒ Static IP ☐ Dynamic IP

IP address: 192.168.101.204

Subnet mask: 255.255.255.0

Default gateway: 192.168.101.1

DNS server: 114.114.114.114

Save Reset

* need to reboot to take effect after save

Network mode

☒ Wired

Save

* need to reboot after a switch to take effect

c. Set WAN IP;


'IP address' set as 192.168.1.4;

'Subnet mask' set as 255.255.255.0;

'Default Gateway' set as 192.168.1.1;

'DNS Server' should be the same as the DNS server IP in the project;

After finished Setting IP Address above, click '**Save**' button.



WAN: ☒ Static IP ☐ Dynamic IP

IP address: 192.168.1.4

Subnet mask: 255.255.255.0


Default gateway: 192.168.1.1

DNS server: 114.114.114.114

* need

1. Click Save

d. Restart the BACnet gateway, enable the new IP address



Basic Advanced

Restart the gateway

Click on the restart, the gateway to resume operation

1. Click Reboot


2. Click Reboot

Note:

Now the final IP address is 192.168.1.4. If you want to access the gateway web page, we should use 192.168.1.4 replace of 192.168.100.126.

8. Wireless Network Centralized Control System

8.1 Overall Structure



8.2 Operating Method

1) Install the specialized control software to mobile terminal

- For Android system , install the following specialized software



- For iPhone device

Pls. download at the following website

a) <http://www.logicsolutions.com.cn/store/auxapp.php>

b) <http://www.logicsolutions.com.cn/store/auxiphone.php>

NINGBO AUX ELECTRIC CO.,LTD

Add: NO. 1166 North Mingguang Road, Jiangshan, Ningbo, Zhejinag, PR. China

E-mail:auxcac@mail.auxgroup.com

[Http://auxcac.cn](http://auxcac.cn)

Tel:+86-574-88220564

The above designs and specifications are subject to charge without prior notice. Final specifications please refer to latest technical specification provided by sales representative.



NINGBO AUX ELECTRIC CO.,LTD